



SANYO DENKI

Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

SANNOTION K DC SERVO SYSTEMS

Input voltage 24 VDC, 75 VDC

Servo motor



Flange size 42, 54, 76, 88 mm



Rated output 23 to 500 W



Contents

Features p. 4
System Configuration Example p. 5
How to Read Model Numbersp. 7
Standard Model Number Listp. 8
Specifications p. 10
Common Specificationsp. 14
Encoder Specifications p. 15
Dimensions p. 16
Selection Guidep. 24
Safety Precautions


SANMOTION DC SERVO SYSTEMS

The SANMOTION K DC servo motors achieve smooth operation, high efficiency, and low noise. These motors are suitable for applications requiring high precision, including precision measuring instruments and medical equipment.

Features


High accuracy (Smooth operation)

Cogging torque has been reduced by up to half compared with our conventional DC servo motors.* This enables smooth motor operation even at low speeds, improving the accuracy of equipment movements.



Low noise

Brush vibrations have been reduced, and the rigidity of motor parts has been improved. Compared with our conventional DC servo motors,* noise levels have been reduced by up to 8 dB.




Low-voltage models available

In addition to 75 VDC class models, low-voltage (24 VDC class) models are also available. The low-voltage models are safe for use in medical equipment and other applications close to people.

* Compared with our conventional SANMOTION T DC servo motors.

Energy-saving (High efficiency)

Power loss has been reduced by up to approximately 30% and efficiency has been increased by 10% compared with our conventional DC servo motors.* This reduces heat generation within equipment and contributes to energy savings.



IP43 protection rating

→page 14


All servo motors have a protection rating of IP43.





System Configuration Example

Contact us if you need an amplifier.



Servo motor

Low Cogging Torque, Low Loss, Low Noise

Output capacity: 23 to 500 W

For 42 and 54 mm motors, low-voltage (24 VDC) models are also available.

How to read model numbers

30

7

Α

К

Not all combinations of descriptions below are valid. For model numbers valid as standard products, refer to "Standard Model Number List."

S0

В



					Code	Pulses per revolution	Output circuit	Remark
					XX	—	-	Standa
					S0	2000		Stanua
					S6	200	Line driver	
					S7	500	Line driver	
					S8	1000		
					C0	2000		Option
					C6	200	Open collector	
					C7	500		
					C8	1000		
				Holdin	ig brake / T	achogenerator		
				Code		Tachogenerat	or Remarks	
				<u> </u>	_	_	Standard	
				<u> </u>	90 VDC			
				<u> </u>	24 VD0		Options	
					48 VDC	,		
					90 VDC	<u> </u>	Standard	
				 	24 VDC			
				К	48 VDC		Options	
			Rated	output			L	
				Specifications	F	Remarks		
			02	23 W				
			04	40 W				
			06	60 W				
			08	80 W				
			11	80 W		DC input voltage		
	-			110 W	For 75 VI	DC input voltage		
L	Flange	SIZE	20	200 W				
	Code	Specifications	30	300 W				
	4	42 mm sq.	40	400 W				
	5	54 mm sq.	50	500 W				
	7	76 mm sq.						
	8	88 mm sq.						
Input	t voltage							
Cod	le Input voltag	e Rer	narks					
A	75 VDC clas	s						

Standard Model Number List

Input voltage 24 VDC class (Low-voltage model)

	Rated			Holding brake		Pa	ige
Flange size	output	Encoder	Tachogenerator	(90 VDC)	Model no.	Specifications	
		—	_	_	KB402XXX	p. 10	p. 16
	23 W	\checkmark	_	_	KB402XS0	р. 10	p. 17
		—	\checkmark	_	KB402TXX	р. 10	p. 18
		—	—	—	KB404XXX	p. 10	p. 16
42 mm sq.	40 W	\checkmark	—	—	KB404XS0	p. 10	р. 17
		—	\checkmark	—	KB404TXX	p. 10	p. 18
		—	—	—	KB406XXX	p. 10	p. 16
	60 W	\checkmark	—	—	KB406XS0	p. 10	p. 17
		—	✓	—	KB406TXX	p. 10	p. 18
		—	—	—	KB506XXX	p. 11	p. 16
		\checkmark	—	—	KB506XS0	p. 11	p. 17
		—	\checkmark	—	KB506TXX	p. 11	p. 18
	60 W	—	—	\checkmark	KB506BXX	p. 11	p. 19
	00 00	\checkmark	_	✓	KB506BS0	p. 11	p. 20
		—	✓	~	KB506JXX	p. 11	p. 21
		\checkmark	✓	—	KB506TS0	p. 11	p. 22
E4 mana ag		\checkmark	✓	✓	KB506JS0	p. 11	p. 23
54 mm sq.		—	—	—	KB511XXX	p. 11	p. 16
		\checkmark	—	—	KB511XS0	p. 11	p. 17
		—	✓	—	KB511TXX	p. 11	p. 18
	80 W	_	_	~	KB511BXX	p. 11	p. 19
	00 00	\checkmark	_	~	KB511BS0	p. 11	p. 20
		—	✓	\checkmark	KB511JXX	p. 11	p. 21
		\checkmark	✓	_	KB511TS0	p. 11	p. 22
		\checkmark	✓	~	KB511JS0	p. 11	p. 23

Options

Brush (Maintenance parts)

Applicable product	Model no.	Quantity
For 42 mm sq. motors	AL-01027427	2 pcs
For 54 mm sq. motors	AL-01027428	2 pcs (60 W, 110 W), 4 pcs (80 W)
For 76 mm sq. motors	AL-01027429	4 pcs
For 88 mm sq. motors	AL-01027430	4 pcs
For 42 mm sq. tachogenerators	S813053-1A-87	2 pcs
For 54 mm sq. tachogenerators	S782281-1A-87	2 pcs
For 76 and 88 mm sq. tachogenerators	S782279-1A-87	2 pcs

-	Rated	_		Holding brake		Pa	ige
Flange size	output	Encoder	Tachogenerator	(90 VDC)	Model no.	Specifications	
		—	—	—	KA404XXX	p. 12	p. 16
	40 W	\checkmark	—	_	KA404XS0	p. 12	p. 17
42 mm sq.		—	✓	—	KA404TXX	p. 12	p. 18
42 mm 5q.		—	—	—	KA406XXX	p. 12	p. 16
	60 W	\checkmark	—	—	KA406XS0	p. 12	p. 17
		—	\checkmark	—	KA406TXX	p. 12	p. 18
		—	_	—	KA506XXX	p. 12	p. 16
		\checkmark	—	—	KA506XS0	p. 12	p. 17
		—	\checkmark	—	KA506TXX	p. 12	p. 18
	60 W	—	—	\checkmark	KA506BXX	p. 12	p. 19
	60 00	\checkmark	—	\checkmark	KA506BS0	p. 12	p. 20
		_	\checkmark	~	KA506JXX	p. 12	p. 21
		~	✓	—	KA506TS0	p. 12	p. 22
F 4		~	✓	~	KA506JS0	p. 12	p. 23
54 mm sq.		_	_	_	KA511XXX	p. 12	p. 16
		~	_	_	KA511XS0	p. 12	p. 17
		_	✓	_	KA511TXX	p. 12	p. 18
		_	_	✓	KA511BXX	p. 12	p. 19
	110 W -	✓	_	✓	KA511BS0	p. 12	p. 20
			✓	· · · · · · · · · · · · · · · · · · ·	KA511JXX	p. 12	p. 21
		~	· · · · · · · · · · · · · · · · · · ·		KA511TS0	p. 12	p. 22
		· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	✓	KA511JS0	p. 12	p. 22
					KA720XXX	p. 12	p. 20
		~			KA720XS0	р. 13 р. 13	p. 10
	-	<u> </u>	✓		KA720XXX	р. 13 р. 13	p. 17
	-		• —	✓	KA720TXX KA720BXX	p. 13	p. 10
	200 W -	√		<u>→</u> ✓	KA720BXX KA720BS0	р. 13 р. 13	p. 13
	-	✓			KA720B30 KA720JXX	р. 13 р. 13	
			✓ ✓	✓	KA720JXX KA720TS0		p. 21
	-	<u> </u>				p. 13	p. 22
76 mm sq.		\checkmark	✓	\checkmark	KA720JS0	p. 13	p. 23
•	-			—	KA730XXX	p. 13	p. 16
		✓			KA730XS0	p. 13	p. 17
			✓		KA730TXX	p. 13	p. 18
	300 W -		—	✓	KA730BXX	p. 13	p. 19
		✓	_	✓	KA730BS0	p. 13	p. 20
		—	✓	\checkmark	KA730JXX	p. 13	p. 21
		✓	✓	_	KA730TS0	p. 13	p. 22
		✓	✓	✓	KA730JS0	p. 13	p. 23
		—		—	KA840XXX	p. 13	p. 16
		\checkmark	-	—	KA840XS0	p. 13	p. 17
		_	✓	_	KA840TXX	p. 13	p. 18
	400 W	—	—	\checkmark	KA840BXX	p. 13	p. 19
	400 VV	~	—	\checkmark	KA840BS0	р. 13	p. 20
		_	✓	\checkmark	KA840JXX	р. 13	p. 21
		\checkmark	✓		KA840TS0	p. 13	p. 22
00 mm ac		\checkmark	\checkmark	\checkmark	KA840JS0	p. 13	p. 23
88 mm sq.			-	_	KA850XXX	p. 13	p. 16
		~	_	-	KA850XS0	р. 13	р. 17
		_	✓	_	KA850TXX	p. 13	p. 18
		_	_	~	KA850BXX	p. 13	p. 19
	500 W	✓	_	✓	KA850BS0	p. 13	p. 20
			✓	· · · · · · · · · · · · · · · · · · ·	KA850JXX	p. 13	p. 20
		~	· · · · · · · · · · · · · · · · · · ·	• —	KA850TS0	p. 13	p. 21
		· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	✓	KA850JS0	p. 10	p. 22

Input voltage 75 VDC class

Specifications

Input voltage 24 VDC class (Low-voltage model)


Sei	vo motor model no. Inside (《》ind	icates mo	otor flange size	KB402	KB404	KB406		
		Condition	Symbol	Unit	《42 mm sq.》	《42 mm sq.》	《42 mm sq.》		
	Rated output	☆☆	P _R	W	23	40	60		
	Rated armature voltage	☆☆	V _R	V	20	24	24		
	Rated torque	☆☆	T _R	N∙m	0.074	0.13	0.19		
	Rated armature current	☆☆	I _R	А	1.8	2.7	4.1		
	Rated speed	☆☆	N _B	min ⁻¹	3000	3000	3000		
	Continuous stall torque	☆☆	Ts	N∙m	0.08	0.14	0.20		
	Peak stall torque	☆☆	$T_{P}(N)$	N∙m	0.42	0.76	1.2		
	Armature stall current	☆☆	I _s	A	1.8	2.7	4.1		
5	Peak armature stall current	☆☆	$I_{P}(N)$	A	10	14	23		
INIOLOF	Maximum speed		N _{max}	min ⁻¹	5000	5000	5000		
-	Rated power rate	☆☆	Q _R	kW/s	1.2	2.0	3.3		
	Torque constant	☆	Κ _T	N•m/A	0.047	0.057	0.056		
	Voltage constant	☆	K _E	×10 ⁻³ V/min ⁻¹	4.9	6.0	5.9		
	Rotor inertia		J _M	×10⁻⁴kg•m²	0.047	0.084	0.108		
	Armature winding resistance	☆	Ra	Ω	3.2	1.7	0.94		
	Armature inductance	☆	La	mH	0.9	0.7	0.5		
	Mechanical time constant	☆	tm	ms	6.9	4.4	3.2		
	Electrical time constant	☆	te	ms	0.28	0.41	0.53		
	Coefficient of voltage generated	☆	K _{EG}	V/min ⁻¹		3×10 ⁻³ ±10%			
5	Effective (rms) ripple	☆	\mathcal{E}_{s}	%		2			
a.	Peak-to-peak ripple	☆	Es	%		5			
Ð	Linearity	☆	δ_{L}	%		1			
JGE	Armature winding resistance	☆	R ₁	Ω		37			
lacnogenerator	Armature inductance	☆	L ₁	mH	5				
σ	Minimum load resistance	☆	RL	kΩ	10				
	Rotor inertia		J _{TG}	×10 ^{-₄} kg•m²		0.011			
	Voltage	☆	V _B	V					
Ð	Current	Å	I _B	A					
brake	Holding torque	☆☆	Τ _B	N∙m					
ñ	Inertia		J _B	×10 ^{-₄} kg•m²					
	Resistance	☆	R _B	Ω					
	Mas	s			See the Dimensions section				
iz	e of aluminum plates for heat d	issipat	ion durin	g measurement	250 × 250 × 6 mm				
	an par revolution for another		Line	driver	Standard	l: 2000 ^P / _R Optional: 200, 500), 1000 ^P / _R		
ul	ses per revolution for encoder		Open c	ollector	Οι	otional: 200, 500, 1000, 2000	P/R		
_					-				

Oil seal

The values in the row with " \dot{x} " are for when the ambient temperature and armature winding temperature are 25°C.

The values in the row with " $\dot{x}\dot{x}$ " are after thermal equilibrium is established. The values in the table above are for when operated with a stable DC current at ambient temperatures below 40°C.

The values for the tachogenerator are for when the test circuit shown below is used.




Encoders can not be installed to KB4 models with a tachogenerator. The holding brake cannot be used for dynamic braking.

Holding brakes are also available in 24 and 48 V. (Optional)


Specifications are subject to change without notice.

24 VDC class models (low-voltage models) are outside the scope of CE marking and UKCA marking.





KB506	KB511	Servo motor	model no	. Inside	《》 indicates motor flange s	ize		
《54 mm sq.》	《54 mm sq.》	Unit	Symbol	Condition				
60	80	W	P _R	☆☆	Rated output			
24	24 24		V _B	☆☆	Rated armature voltage			
0.19	0.26	N∙m	T _R	☆☆	Rated torque	1		
3.9	5.0	A	I _R	☆☆	Rated armature current	1		
3000	3000	min ⁻¹	N _B	☆☆	Rated speed	1		
0.24	0.32	N∙m	Ts	☆☆	Continuous stall torque	1		
1.8	2.16	N∙m	$T_{P}(N)$	☆☆	Peak stall torque			
4.5	5.2	A	I _s	☆☆	Armature stall current			
31	40	A	I _P (N)	☆☆	Peak armature stall current	5		
5000	5000	min ⁻¹	N _{max}		Maximum speed	Motor		
1.6	1.8	kW/s	O _R	☆☆	Rated power rate	2		
0.057	0.06	N•m/A	K _T	\$	Torque constant			
6.0	6.3	×10 ⁻³ V/min ⁻¹	K _E	\$	Voltage constant			
0.22	0.37	×10 ⁻⁴ kg•m ²	J _M		Rotor inertia			
1.1	0.44	Ω	Ra	☆	Armature winding resistance			
0.5	0.3	mH	La	\$	Armature inductance			
7.4	4.5	ms	tm	\$	Mechanical time constant			
0.45	0.61	ms	te	☆	Electrical time constant			
7×10 ⁻³	±10%	V/min ⁻¹	K _{EG}	☆	Coefficient of voltage generated			
1		%	εs	☆	Effective (rms) ripple	2		
3	1	%	Es	☆	Peak-to-peak ripple	Tachogenerator		
1		%	δ_{L}	☆	Linearity	ne		
20	6	Ω	R ₁	☆	Armature winding resistance] ge		
4.	1	mH	L ₁	☆	Armature inductance	ch (
1(0	kΩ	RL	☆	Minimum load resistance	_a [
0.1	2	×10 ⁻⁴ kg∙m²	J _{TG}		Rotor inertia			
90±1	0%	V	V _B	☆	Voltage			
0.0	06	A	I _B	☆	Current	b		
0.2	0.29			☆☆	Holding torque	Brake		
0.01		×10 ⁻⁴ kg•m²	J _B		Inertia	Ē		
160	1600			\$	Resistance			
See the Dimer	See the Dimensions section			M	ass			
305 × 305	305 × 305 × 12 mm			s for heat	dissipation during measurem	ent		
	Standard: 2000 ^P / _R Optional: 200, 500, 1000 ^P / _R			Line driver				
Optional: 200, 50	Optional: 200, 500, 1000, 2000 ^P / _R				Open collector Pulses per revolution for encoder			
Can be	used			Oil	seal			




Input voltage 75 VDC class


Servo motor model no. Inside	《 》indi	icates mo	otor flange size	KA404	KA406	KA506	KA511
	Condition	Symbol	Unit	《42 mm sq.》	《42 mm sq.》	《54 mm sq.》	《54 mm sq.》
Rated output	☆☆	P _R	W	40	60	60	110
Rated armature voltage	☆☆	V _R	V	72	70	75	75
Rated torque	☆☆	T _R	N∙m	0.13	0.19	0.19	0.35
Rated armature current	☆☆	I _R	А	0.9	1.2	1.1	2.0
Rated speed	☆☆	N _R	min ⁻¹	3000	3000	3000	3000
Continuous stall torque	☆☆	Ts	N∙m	0.14	0.20	0.24	0.42
Peak stall torque	☆☆	T _P (N)	N∙m	0.76	1.2	1.8	3.4
Armature stall current	☆☆	I _s	А	0.9	1.2	1.4	2.1
Peak armature stall current	☆☆	I _P (N)	A	4.7	7.6	10	18
Peak armature stall current Maximum speed		N _{max}	min ⁻¹	5000	5000	5000	5000
Rated power rate	☆☆	O _R	kW/s	2.0	3.3	1.6	3.3
Torque constant	☆	Κ _τ	N•m/A	0.174	0.177	0.17	0.20
Voltage constant	☆	K _E	×10 ⁻³ V/min ⁻¹	18.2	18.5	17.8	20.8
Rotor inertia		J _M	×10 ^{-₄} kg∙m²	0.084	0.108	0.22	0.37
Armature winding resistance	☆	Ra	Ω	16.8	9.8	9.4	4.8
Armature inductance	☆	La	mH	7.6	4.5	4.4	3.0
Mechanical time constant	☆	tm	ms	4.7	3.4	7.2	4.5
Electrical time constant	☆	te	ms	0.45	0.46	0.47	0.63
Coefficient of voltage generated	☆	K _{EG}	V/min ⁻¹	3×10 ⁻³	³ ±10%	7×10 ⁻³	±10%
5 Effective (rms) ripple	☆	εs	%	:	2		
Peak-to-peak ripple	☆	ε _R	%	Į	5	3	
Linearity	☆	δ_{L}	%		1		
Effective (rms) ripple Peak-to-peak ripple Linearity Armature winding resistance Armature inductance Minimum load resistance	☆	R ₁	Ω	3	37	26	
Armature inductance	☆	L1	mH	Į	5	4.	.1
Minimum load resistance	☆	RL	kΩ	1	0	1	0
Rotor inertia		J _{TG}	×10 ⁻⁴ kg∙m²	0.0)11	0.	12
Voltage	☆	V _B	V			90±	10%
D Current	\$	I _B	А			0.0	06
Holding torque	☆☆	Τ _B	N∙m			0.1	29
nertia		J _B	×10 ⁻⁴ kg∙m²			0.0	01
Resistance	\$	R _B	Ω			16	00
Ma	ISS				See the Dime	nsions section	
ize of aluminum plates for heat	dissipati	on during	g measurement		0 × 6 mm	305 × 305	
ulses per revolution for encoder		Line o	driver	St		ional: 200, 500, 1000	P/R
		Open c	ollector	Optional: 200, 500, 1000, 2000 ^P / _R			
Oil s	seal					Can be	e used

The values in the row with " $\dot{x}\dot{x}$ " are after thermal equilibrium is established. The values in the table above are for when operated with a stable DC current at ambient temperatures below 40°C.


The values for the tachogenerator are for when the test circuit shown below is used.



Encoders can not be installed to KB4 models with a tachogenerator. The holding brake cannot be used for dynamic braking. Holding brakes are also available in 24 and 48 V. (Optional) Specifications are subject to change without notice.



KA720	KA730	KA840	KA850	Servo motor r	nodel no	. Inside	e《》indicates motor flange	size
《76 mm sq.》	《76 mm sq.》	《88 mm sq.》	《88 mm sq.》	Unit	Symbol	Condition		
200	300	400	500	W	P _R	☆☆	Rated output	
80	75	85	80	V	V _R	☆☆	Rated armature voltage	
0.64	1.15	1.53	1.91	N∙m	T _R	☆☆	Rated torque]
3.4	4.8	5.7	7.4	A	I _R	☆☆	Rated armature current	
3000	2500	2500	2500	min ⁻¹	N _R	☆☆	Rated speed	1
0.77	1.43	1.70	2.16	N∙m	Ts	☆☆	Continuous stall torque	
5.4	9.8	12	16.7	N∙m	T _P (N)	☆☆	Peak stall torque	1
3.6	5.4	6.0	7.6	A	I _s	☆☆	Armature stall current	
25	40	40	62	A	I _P (N)	☆☆	Peak armature stall current	ō
5000	4000	4000	3000	min ⁻¹	N _{max}		Maximum speed	Motor
2.8	4.9	4.7	6.1	kW/s	O _R	☆☆	Rated power rate	
0.23	0.27	0.31	0.286	N∙m/A	Κ _T	☆	Torque constant	
24.2	28.6	32.9	30.0	×10 ⁻³ V/min ⁻¹	K _E	\$	Voltage constant]
1.47	2.7	5.0	6.0	×10 ⁻⁴ kg∙m²	J _M		Rotor inertia	
2.2	1.05	0.95	0.53	Ω	Ra	\$	Armature winding resistance]
3.3	1.7	1.5	0.86	mH	La	☆	Armature inductance	
6.1	3.8	4.8	3.9	ms	tm	\$	Mechanical time constant	
1.5	1.6	1.5	1.6	ms	te	☆	Electrical time constant	
	7×10 ⁻⁵	³ ±10%		V/min ⁻¹	K _{EG}	☆	Coefficient of voltage generated	
		1		%	\mathcal{E}_{s}	☆	Effective (rms) ripple	٦ د
	:	3		%	\mathcal{E}_{R}	☆	Peak-to-peak ripple	Tachogenerator
		1		%	δ_{L}	☆	Linearity	ne
	2	6		Ω	R ₁	☆	Armature winding resistance	oge
	4	.1		mH	L ₁	☆	Armature inductance	chc
	1	0		kΩ	RL	☆	Minimum load resistance	Ta
	0.	12		×10 ⁻⁴ kg∙m²	J _{TG}		Rotor inertia	
90±1	10%	90±	10%	V	V _B	☆	Voltage	
0.1	11	0.	11	A	I _B	\$	Current	e
1.47		1.	96	N∙m	Τ _B	☆☆	Holding torque	Brake
0.09 0.2		.2	×10⁻⁴kg•m²	J _B		Inertia	В	
82	820 820					☆	Resistance	
			N	lass				
	305 × 305 × 12 mm					for hea	t dissipation during measuren	nent
Sta		ional: 200, 500, 1000	P/R	Line	Line driver Pulses per revolution for encode			oder
		00, 1000, 2000 ^P / _R		Open collector			Juer	
	Can be used					Oil	seal	




Common Specifications

Specifications common to all motors

Items	Specifications
Rated	Continuous (S1)
Thermal class	F
Excitation system	Permanent magnet
Insulation resistance	10 M Ω or more at 500 VDC
Dielectric strength	1500 VAC (600 V for 24 V class and tachogenerator models), for one minute (However, do not measure dielectric strength between encoder and motor)
Rotation	Forward and reverse rotations possible
Ambient temperature	0 to 40°C
Humidity	20 to 90% RH (non-condensing)
Paint color	Black
Protection	Fully enclosed (IP43)
Lead wire length	1000 mm

How to connect



Motor rotation direction


When (Red): + and (Blue): -, counterclockwise as viewed from the output axis

Tachogenerator polarity

When rotating counterclockwise as viewed from the output axis, (Red): + and (Blue): -

Protection rating

The protection ratings of our servo motors comply with IEC standards (IEC 60034-5 Edition 4.1, 2006-11).



Compliance with International Standards and Directives

UL, c-UL



E179832(PRHZ2, PRHZ8)

	Directive	Standards		
CE marking in Europe	Low Voltage Directive 2014/35/EU	IEC 60034-1, IEC60034-5 Only 75 VDC class models are CE marking-compliant. 24 VDC class models are outside the scope of CE marking.		
	RoHS Directive 2011/65/EU	EN IEC 63000 : 2018		
UKCA marking in Great Britain In compliance from July 2022	Electrical Equipment (safety) Regulaton 2016	IEC 60034-1, IEC60034-5 Only 75 VDC class models are UKCA marking-co 24 VDC class models are outside the scope of UK	•	
production onwards.	RoHS Regulations 2012	EN IEC 63000 : 2018		
	Directive	Standards	File no.	

UL

UL1004-1, UL1004-6, CSA_C22.2_No.100

Encoder Specifications

Items	Unit	Specifications
Encoder type		Incremental encoder
Pulses per revolution	P/R	Standard: 2000 (Optional: 200, 500, 1000)
Output circuit		Line driver
Number of channels		3
Power supply	VDC	+5±5%
Current consumption	mA	160 max.
Output circuit voltage	VDC	V _{OH} =2.4 min., V _{OL} =0.5 max.
	100	at $I_0 = \pm 20 \text{ mA}$
Output circuit current	mA	20 max.
Response frequency	kHz	200
PWM duty cycle		$T_1 = 1/2T_0 \pm 1/8T_0$
Output phase difference		$T_{2 \text{ to } 5} = 1/4T_0 \pm 1/8T_0$
Zero-point signal		$T_6 = T_0 \pm 0.4 T_0$
Operating temperature	°C	0 to +85 (inside the encoder)
Inertia	×10 ⁻⁴ kgm²	0.005


Note: An open collector output type is also available as an option.

External connection

Lead wire color	Application
Red	+5 VDC
Black	GND(0V)
Shielded	Chassis ground
Blue	A-channel output
Brown	Ā-channel output
Green	B-channel output
Purple	B-channel output
White	Z-channel output (zero point)
Yellow	\overline{Z} -channel output (zero point)

Output waveform

•Line driver output (When rotating counterclockwise as viewed from the motor output shaft)



 $^{\ast}\,T_{0}$ is the average time for one encoder rotation when the encoder is rotated at a constant speed.


• Do not exert forces in the axial direction when handling.

• Do not perform insulation resistance or dielectric strength testing as it may damage the electronic circuit.

•The specifications above do not take deviations arising from motor dependencies into account.

Dimensions


Servo motor



											(Unit: mm)
Model No.	LL	LG	L1	L2	LA	LB	LE	LH	LC	LZ	LR
KB402XXX	56±1		40.5			_					
K□404XXX	69±1		53.5	11.5	48±0.2	0 34-0.025	2±0.3	56	42±0.5	4- <i>ф</i> 3.5	
K□406XXX	82±1	5±0.5	66.5]		010.020					24±0.8
KD506XXX	81±1		58	17	60±0.3	0	2.5±0.3	69	54±0.5	1 41 5	
KD511XXX	101±2		78		00±0.3	50-0.025	2.5±0.3	69	54±0.5	4 <i>-ϕ</i> 4.5	
KA720XXX	100.5±2		74.5	17.5	90±0.3	0		100	76±0.8	1 4 5 5	30±0.8
KA730XXX	124.5±2	8±0.5	98.5	17.5	90±0.3	70-0.030		100	70±0.0	4 <i>-φ</i> 5.5	30±0.8
KA840XXX	134±2	0±0.5	103.5	22	100±0.3	0	3±0.4	112	88±0.8	1 46 6	25.0.9
KA850XXX	149±2]	118.5	22 10	100±0.3	80-0.030			00±0.8	4 <i>-ϕ</i> 6.6	35±0.8

Model No.	S	٥	QA	QK	W	Т	U	М	LT	Mass [kg]
KB402XXX										0.30
K⊡404XXX										0.40
K□406XXX	0 7 -0.009	20±0.5	-	15±1.5	Two slot	s 6.5±0	.2	_	-	0.50
K_506XXX	, 0.000									0.70
KD511XXX										0.90
KA720XXX	0	25±0.5		20,07				M5	8	1.80
KA730XXX	14 -0.011	25±0.5	2	20±0.7	+0.024 5+0.012	5	0	CIVI	0	2.50
KA840XXX	0	30±0.5	2	25±0.7		5	2-0.2	M6	10	3.40
KA850XXX	16 -0.011	30±0.5		25±0.7				IVIO	10	4.10

Servo motor with encoder




												(Unit: mm)
Model No.	LL	LG	L1	L2	L3	LA	LB	LE	LH	LC	LZ	LR
KB402XS0	83±1		40.5				_					
K <u></u> 404XS0	96±1		53.5	11.5	9	48±0.2	0 34-0.025	2±0.3	56	42±0.5	4- <i>ф</i> 3.5	
K□406XS0	109±2	5±0.5	66.5				010.020					24±0.8
K□506XS0	110.5±2		58	17	20	60±0.3	0	2.5±0.3	69	54±0.5	4 <i>-0</i> 4.5	
K[]511XS0	130.5±2		78		20	00±0.3	50-0.025	2.5±0.3	09	54±0.5	4- <i>ψ</i> 4.5	
KA720XS0	134.5±2		74.5	17.5	27	90±0.3	0		100	76±0.8	1 4 5 5	30±0.8
KA730XS0	158.5±2	8±0.5	98.5	17.5	27	90±0.3	70-0.030	3±0.4	100	70±0.0	4 <i>-φ</i> 5.5	30±0.0
KA840XS0	166±2	0±0.5	103.5	22	05	100±0.3	0	3±0.4	112	88±0.8	1 46 6	35±0.8
KA850XS0	181±2	1	118.5		25	100±0.3	80-0.030		112	00±0.8	4 <i>-\$</i> 6.6	0.8±0.8

Model No.	S	٥	QA	QK	W	Т	U	М	LT	Mass [kg]
KB402XS0										0.40
K_404XS0										0.55
K□406XS0	0	20±0.5	-	15±1.5	Two slot	s 6.5±0	.2	-	-	0.65
K_506XS0										0.80
K[]511XS0										1.10
KA720XS0	0	25±0.5		20±0.7				M5	8	2.10
KA730XS0	14 -0.011	25±0.5	2	20±0.7	+0.024	5	0	CIVI	0	3.10
KA840XS0	0	30±0.5	Z	25±0.7	5+0.012	э	2-0.2	M6	10	3.65
KA850XS0	16 -0.011	30±0.5		25±0.7				IVIO	10	4.25

Dimensions


Servo motor with tachogenerator




												(Unit: mm)
Model No.	LL	LG	L1	L2	L3	LA	LB	LE	LH	LC	LZ	LR
KB402TXX	85±1		40.5									
K⊡404TXX	98±1		53.5	11.5	23	48±0.2	0 34-0.025	2±0.3	56	42±0.5	4 <i>-ф</i> 3.5	
K⊡406TXX	111±2	5±0.5	66.5				010.020					24±0.8
K⊡506TXX	124.5±2		58	17	28	60±0.3	0	2.5±0.3	69	54±0.5	1 41 5	
K_511TXX	144.5±2		78		20	00±0.3	50-0.025	2.5±0.3	09	54±0.5	4 <i>-ϕ</i> 4.5	
KA720TXX	148.5±2		74.5	17.5	34	90±0.3	0		100	76±0.8	4 45 5	30±0.8
KA730TXX	172.5±2	0.05	98.5	17.5	34	90±0.3	70-0.030	2.0.4	100	70±0.8	4 <i>-φ</i> 5.5	30±0.8
KA840TXX	183±2	8±0.5	103.5	22	22	100.0.2	0	3±0.4	110	00.00	1 40 0	25.0.0
KA850TXX	197.5±2		118.5	22	33	100±0.3	80-0.030		112	88±0.8	4 <i>-φ</i> 6.6	35±0.8

Model No.	S	٥	QA	QK	W	Т	U	М	LT	Mass [kg]
KB402TXX										0.34
K⊡404TXX										0.49
K□406TXX	0	20±0.5	-	15±1.5	Two slot	s 6.5±0	.2	-	-	0.59
K⊡506TXX	, 0.000									1.0
KD511TXX										1.21
KA720TXX	0	25±0.5		20±0.7				M5	8	2.15
KA730TXX	14 -0.011	25±0.5	2	20±0.7	+0.024	5	0	IVID	0	2.85
KA840TXX	0	30±0.5	2	25±0.7	5+0.012) D	2-0.2	M6	10	3.85
KA850TXX	16 -0.011	30±0.5		25±0.7				IVIO	10	4.45

Servo motor with holding brake






Model No.	LL	LG	L1	L2	L3	LA	LB	LE	LH	LC	LZ	LR
K_506BXX	118±2	5±0.5	58	17	28.5	60±0.3	0	2.5±0.3	69	54±0.5	4 <i>-0</i> 4.5	24±0.8
K_511BXX	138±2	5±0.5	78	17	20.0	00±0.3	50-0.025	2.0±0.3	09	54±0.5	4-ψ4.5	24±0.0
KA720BXX	138.5±2		74.5	17.5	30.5	90±0.3	0		100	76±0.8	4 <i>-0</i> 5.5	30±0.8
KA730BXX	162.5±2	8±0.5	98.5	17.5	30.5	90±0.3	70-0.030	3±0.4	100	70±0.0	4-ψ5.5	30±0.0
KA840BXX	169.5±2	0±0.5	103.5	22	27	100±0.3	0	5±0.4	112	88±0.8	4 <i>-ø</i> 6.6	35±0.8
KA850BXX	184.5±2		118.5	22	21	100±0.5	80-0.030		112	00±0.0	4-ψ0.0	30±0.0

Model No.	S	Q	QA	QK	W	Т	U	М	LT	Mass [kg]
KD506BXX	0	20±0.5	_	15±1.5	Two slot	- 6 E +0	n	_	_	0.91
KD511BXX	7 -0.009	20±0.5		15±1.5		s 0.5⊥0	.2			1.21
KA720BXX	0	25±0.5		20±0.7				M5	8	2.39
KA730BXX	14 -0.011	25±0.5	2	20±0.7	+0.024	5	0	CIVI	0	3.09
KA840BXX	0	30±0.5	Z	25±0.7	5+0.012	5	2-0.2	M6	10	4.20
KA850BXX	16 -0.011	30±0.5		25±0.7				IVIO	10	4.79

(Unit: mm)

Dimensions


Servo motor with encoder and holding brake




Model No.	LL	LG	L1	L2	L3	L4	LA	LB	LE	LH	LC	LZ
K_506BS0	147±2	5±0.5	58	17	28.5	28	60±0.3	0	2.5±0.3	69	54±0.5	4- <i>0</i> 4.5
K_511BS0	167±2	5±0.5	78		20.0	20	00±0.3	50-0.025	2.0±0.3	03	54±0.5	4-ψ4.5
KA720BS0	172.5±2		74.5	17.5	30.5	34.5	90±0.3	0		100	76±0.8	4- <i>0</i> 5.5
KA730BS0	196.5±2	8±0.5	98.5	17.5	30.5	54.5	90±0.3	70-0.030	3±0.4	100	70±0.8	4-ψ5.5
KA840BS0	203±3	0±0.5	103.5	22	27	35	100±0.3	0	3±0.4	112	88±0.8	4- <i>0</i> 6.6
KA850BS0	218±3		118.5	22	21	35	100±0.5	80-0.030		112	00±0.0	4-ψ0.0

Model No.	LR	S	Q	QA	QK	W	Т	U	М	LT	Mass [kg]
K[]506BS0	24±0.8	0	20±0.5	_	15±1.5	Two slot	- 6 5 +0	n	_	_	1.16
K_511BS0	24±0.0	7 -0.009	20±0.5		15±1.5		S 0.5⊥0	.2			1.46
KA720BS0	30±0.8	0	25±0.5		20±0.7				M5	8	2.64
KA730BS0	30±0.0	14 -0.011	25±0.5	2	20±0.7	+0.024	5	0	IVID	0	3.44
KA840BS0	35±0.8	0	30±0.5	2	25±0.7	5+0.012	5	2-0.2	M6	10	4.44
KA850BS0	35±0.0	16 -0.011	30±0.5		25±0.7				IVIO	10	5.04

Servo motor with tachogenerator and holding brake






												(Unit: mm)
Model No.	LL	LG	L1	L2	L3	L4	LA	LB	LE	LH	LC	LZ
K⊡506JXX	161±2	5±0.5	58	17	28	43.5	60±0.3	0	2.5±0.3	69	54±0.5	4 <i>-ϕ</i> 4.5
K_511JXX	181±2	5±0.5	78		20	43.5	00±0.3	50-0.025	2.0±0.3	03	54±0.5	4-ψ4.5
KA720JXX	186.5±2		74.5	17.5	34	43.5	90±0.3	0		100	76±0.8	4 45 5
KA730JXX	210.5±3	8±0.5	98.5	17.5	- 34	43.5	90±0.3	70-0.030	3±0.4	100	70±0.0	4- <i>ф</i> 5.5
KA840JXX	219.5±3	0±0.5	103.5	22	33	44	100±0.3	0	3±0.4	112	88±0.8	1 46 6
KA850JXX	234.5±3		118.5	22	33	44	100±0.3	80-0.030		112	00±0.8	4- <i>ф</i> 6.6

Model No.	LR	S	۵	QA	QK	W	Т	U	М	LT	Mass [kg]
K□506JXX	24±0.8	0	20±0.5	_	15±1.5	Two slot		2	_	_	1.30
KD511JXX	24±0.0	7 -0.009	20±0.5				5 0.5±0	.2			1.47
KA720JXX	30±0.8	0 25.0	25±0.5	2	20±0.7	+0.024 5+0.012			M5	8	2.80
KA730JXX		14 -0.011	0.011				-	0	IVID		3.40
KA840JXX	35±0.8	0	2	2	2		5	2-0.2	M6	10	4.64
KA850JXX		16 -0.011	30±0.5		25±0.7				IVIO	10	5.24

Dimensions

Servo motor with encoder and tachogenerator





												. ,
Model No.	LL	LG	L1	L2	L3	L4	LA	LB	LE	LH	LC	LZ
K□506TS0	153.5±2	- 5±0.5	58	17	28	35	60±0.3	0 50-0.025	2.5±0.3	69	54±0.5	4- <i>ф</i> 4.5
K_511TS0	173.5±2	5±0.5	78									
KA720TS0	182±2		74.5	17 5	7.5 34	40	90±0.3	0	3±0.4	100	76±0.8	4- <i>ф</i> 5.5
KA730TS0	206±3	0.0E	98.5	17.5				70-0.030				
KA840TS0	216±3	8±0.5	103.5	22	22	42	100±0.3	0		112	88±0.8	1 46 6
KA850TS0	231±3		118.5	22	22 33	42	100±0.3	80-0.030		112	00±0.8	4- <i>ф</i> 6.6

Model No.	LR	S	Q	QA	QK	W	Т	U	М	LT	Mass [kg]
K□506TS0	24±0.8	0	20±0.5	_	15±1.5	Two slot	2	_	_	1.16	
K_511TS0	24±0.0	7 -0.009	20±0.5				.2	_		1.36	
KA720TS0	20.00	0 14 -0.011	25±0.5		20±0.7	+0.024 5+0.012	5	0 2-0.2	M5	8	2.40
KA730TS0	30±0.8		25±0.5						IVID		3.10
KA840TS0	- 35±0.8	0	30±0.5	2	25±0.7				M6	10	4.10
KA850TS0		16 -0.011	30±0.5								4.70

(Unit: mm)

Servo motor with encoder, tachogenerator, and holding brake







												(Unit: mm)
Model No.	LL	LG	L1	L2	L3	L4	L5	LA	LB	LE	LH	LC
K <u></u> 506JS0	190±2	5±0.5	58	17	28	43.5	28	60±0.3	0	2.5±0.3	69	54±0.5
K_511JS0	210±3	5±0.5	78		20				50-0.025	2.5±0.5	03	54±0.5
KA720JS0	220±3		74.5	17.5 34	24	43.5	24 5	00.02	0		100	76.0.0
KA730JS0	244±3	9.0E	98.5		43.5	34.5	90±0.3	70-0.030	2.04	100	76±0.8	
KA840JS0	253±3	8±0.5	103.5	22	33	44	35	100±0.3	0 80-0.030	3±0.4	112	88±0.8
KA850JS0	268±3		118.5	22	33						112	

Model No.	LZ	LR	S	٥	QA	QK	W	Т	U	М	LT	Mass [kg]
K_506JS0	4 44 5	24±0.8	0	20±0.5	_	15±1.5	Two slo		-0.2	_	-	1.42
K_511JS0	4- <i>ф</i> 4.5	24±0.0	7 -0.009	20±0.5			100 50	015 0.01	-0.2			1.62
KA720JS0	4- <i>ф</i> 5.5	-φ5.5 30±0.8	0	25±0.5	- 2	20±0.7	+0.024	5	0 2-0.2	M5	8	3.0
KA730JS0			14 -0.011	25±0.5								3.70
KA840JS0	4- <i>φ</i> 6.6	35±0.8	0 16 -0.011	30±0.5		25±0.7	5+0.012			M6	10	4.90
KA850JS0						20±0.7						5.50

Selection Guide By mechanism

Typical examples of mechanisms and items that require selection are shown below. Provide this information when placing an order.





Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

Safety Precautions

The servo motors in this catalog are designed to be used with general industrial equipment. When using them, pay sufficient attention to the following points.

- Read these Safety Precautions and the included Instruction Manual carefully before installing, assembling, and using the motor for proper use.
- · Do not use the motor in an environment where vibration is present, such as in moving vehicles or shipping vessels.
- · Do not modify or alter the motor in any way.
- · Contact us or your point of sale for installation or maintenance services of the motor.

Consult us or your point of sale when using the motor for the following uses, as these require special considerations for installation, operations, maintenance, and management such as redundancy and emergency power generators.

- Use in medical equipment that may have an effect on human life or the human body
- **2** Use in transportation systems or transport-related equipment such as trains or elevators that may have an effect on human life or the human body
- Use in computer systems or devices that have a major impact on society or on the public
- (1) Use in other devices that have a major impact on human safety or on maintaining public operations

· For use in space, aviation, nuclear power, electric power, and submarine repeaters-related applications, contact us or your point of sale.

Safety Alert Symbols

The following safety symbols are used in the manual to indicate different hazardous situations and prohibited/required actions.

NDANGER Indicates hazards that could cause severe bodily injury or death as a result of failure to follow the instructions.

CAUTION Indicates possible hazards that could cause moderate bodily injury or only property damage as a result of failure to follow the instructions.

Note that even items with a ACAUTION symbol could potentially lead to serious outcomes, depending on the situation.



PROHIBITED Indicates actions that must not be taken.



MANDATORY Indicates actions that must be taken.

General

- Do not use the motor in an explosive, flammable, or corrosive atmosphere (sulfide gas, chlorine gas, ammonia, etc.), in a location exposed to water or corrosive liquids (hydrochloric acid, sulfuric acid, nitric acid, etc.), or near combustible materials. Failure to follow this may cause injury, fire, or damage.
- Only technically qualified personnel should transport, install, wire, operate, or perform maintenance and inspection on the motor. Failure to follow this may cause electric shock, injury, or fire.
- Do not work on wiring, maintenance servicing, or inspection with power on. Perform either of those at least 15 minutes after turning the power off. Failure to follow this may cause electric shock.
- 4. When the protective functions of the motor are activated, turn the power off immediately and eliminate the cause. If restarting the operation without eliminating the cause, the motor may malfunction and cause injury or equipment damage.
- 5. Perform sufficient test runs of the motor to verify operation before actual use. Doing otherwise may cause injury or equipment damage.

Wiring

- Do not connect the servo motor directly to a mains outlet. Failure to follow this may cause electric shock, injury, or fire. The servo motor should be powered by the servo amplifier.
- 7. Use an input voltage within the rated voltage range. Failure to follow this may cause fire or an electric shock.
- Ensure that the servo motor and servo amplifier are grounded. Failure to follow this may cause electric shock.
- 9. Do not damage, apply excessive stress, put heavy things on, or tuck down connectors or cables. Failure to follow this may cause electric shock.
- Connectors and power cables must be wired as instructed in the wiring diagram or the Instruction Manual. Failure to follow this may cause electric shock or fire.
- Our servo motor cables are for fixed-wiring use, so do not use them in applications where flex cables are required. Failure to follow this may cause electric shock, injury, or fire.

▲ CAUTION

General

- Before installation, operation, maintenance servicing, or inspection, be sure to read and follow the Instruction Manual. Failure to follow this may cause electric shock, injury, or fire.
- Do not use the servo motor in conditions that exceed the specification values. Failure to follow this may cause electric shock, injury, or fire.
- 14. Do not insert a finger or an object into the opening of the motor. Failure to follow this may cause electric shock, injury, or fire.
- 15. Do not use a damaged servo motor. Doing so may cause injury or fire.
- If using a servo amplifier, refer to the servo motor characteristics in the catalog when setting its parameters. Failure to follow this may cause fire or product failures.
- 17. Use the servo amplifier and servo motor only after testing them enough in combination. Failure to follow this may cause fire or product failures.
- The servo amplifier, servo motor, and peripheral devices become hot during and after operation, so handle them carefully. Failure to follow this may result in a burn.
- Never disassemble, repair, modify, or alter the motor. Failure to follow this may cause electric shock, injury, or fire.
- 20. Handle the motor with great care to avoid the risk of it falling or tipping over.

Unpacking

- 21. Unpack the box with the right side up. Failure to follow this may cause injury.
- 22. Confirm that the product you received is the one that you have ordered. Installing an incorrect product may cause a damage.

Wiring

- Perform wiring work according to local standards of electrical installations. Failure to follow this may result in burnout or fire.
- 24. Perform wiring correctly and securely. Incorrect wiring may cause the servo motor to run out of control, resulting in injury.
- 25. The power cable for connecting the servo motor and servo amplifier should be longer than the recommended cable length specified in the Instruction Manual. Failure to follow this may cause electric shock or fire.
- 26. The servo motor power cable, input/output signal cable, tachogenerator (DC servo motors only), and encoder cable must not be tied together or passed through the same duct or conduit. Failure to follow this may cause faulty operation.
- Check that the power supply has the right voltage for the servo motor's holding brake. Failure to follow this may cause fire or product damage.
- 28. The surge absorber for the servo motor's holding brake relay prolongs the brake delay time. Therefore, program a sequence taking the delay time into account. Failure to do so may cause the motor to fall, possibly resulting in injury.
- Do not use half-wave rectifier circuits to power the holding brake. Failure to follow this may cause overheating or product failures.

Installation

- 30. The motor output shaft is coated with antirust oil. Wipe it off before installation.
- 31. Install the motor according to the instructions in the Instruction Manual.
- Avoid installing the motor in locations exposed to water, cutting oil, oil mist, iron powder, or metal chips. Failure to follow this may cause electric shock or fire.
- Do not stand on the motor or place heavy objects on top of it. Failure to follow this may cause injury.
- Keep the air intake and exhaust vents free of obstructions and foreign matter. Failure to follow this may cause fire.
- 35. Install the motor with great care to avoid the risk of it falling or tipping over.
- 36. Lift the motor by the eyebolts when transporting motors with eyebolts by

crane.

- Mount the motor to incombustible materials such as metals. Failure to do so may cause fire, injury, or equipment damage.
- Ensure that the servo motor is securely mounted to equipment. Doing otherwise may cause it to fly out while operating.
- Keep any combustible materials away from where the motor is installed. Failure to follow this may result in fire or burns.
- 40. Be sure to secure a ventilation path when installing the motor, and keep the intake and exhaust vents unblocked. Failure to do so may result in electric shock, injury, fire, or equipment damage.
- Check the rotating direction of the motor before connecting it with equipment. Failure to follow this may cause injury or product damage.
- 42. Make sure that oil, flammable foreign objects, or conductive foreign objects such as metal fragments do not get inside the servo motor. Failure to follow this may cause electric shock, fire, or product damage.
- Do not apply excessive force on the connector. Failure to follow this may cause electric shock or fire.
- 44. Do not touch the motor output shaft (especially the keyway and gears) with your bare hand. Failure to follow this may cause injury.
- 45. Do not apply loads to the motor shaft exceeding the specified allowable load. Failure to follow this may cause injury or product damage.
- 46. Make sure that the axial belt tension does not exceed the allowable load when operating the belt drive. The allowable load can be divided into the thrust (axial) load and radial load applied independently in the individual directions to the output shaft.
- 47. When attaching a pulley or coupling to the output shaft of a servo motor, make sure that the motor unbalance is small enough. A large motor unbalance will increase vibration, which may result in shortened service life and premature damage.
- 48. Do not strike the motor shaft with a hammer when installing or removing a coupling to the shaft. Failure to follow this may cause product damage.
- 49. Make sure that the output shaft of the motor and the mating machine are well aligned. Failure to follow this may increase vibration, which may result in shortened service life or premature damage.
- 50. Fix the output shaft of the servo motor to the mating machine around the entire shaft circumference to prevent fretting. Failure to follow this may cause product damage.

Operation

- 51. Servo motors do not come with any protective devices. Ensure safe operation by using safety devices such as an overvoltage protection device, earth leakage breaker, overheat protection device, and emergency stop device. Failure to follow this may cause injury or fire.
- 52. Do not run the motor while loads exceeding the specified allowable load are applied to the motor shaft. Failure to follow this may cause injury or product damage.
- 53. While power is on or for some time after power-off, do not touch the servo motor as it may be hot. Failure to follow this may result in a burn. The temperature of the servo motor rises considerably depending on the operating conditions.
- 54. Stop operations immediately when an emergency occurs. Failure to do so may cause an electric shock, injury, or fire.
- 55. Do not make extreme setting changes as doing so may result in unstable operations. Failure to follow this may cause injury.
- Perform test runs of the motor in an isolated environment, then connect it with equipment. Failure to follow this may cause injury.
- 57. Take safety measures such as covering the rotating parts of the servo motor during operation to prevent them from being touched. Failure to follow this may cause injury.
- When an alarm is activated, remove the cause and ensure safety before resuming operations. Failure to follow this may cause injury.
- 59. Stay away from equipment when power is restored after an outage because the system may restart suddenly. (Make settings on equipment to secure the safety on such occasions.) Failure to follow this may cause injury.
- Use the right power supply for the motor. Failure to follow this may cause product failures.
- The electromagnetic brake is designed to hold the motor position in place. Do not use it as dynamic braking. Failure to follow this may cause equipment damage.
- 62. Secure the key when operating the motor with a key. Failure to follow this may cause injury.
- 63. A rattling noise may occur from the brake when the servo motor is running, but there is no problem with performance.
- 64. Running a servo motor with an oil seal may produce some noise, but there is no problem with performance.

65. For use in applications where varying loads are applied to the shaft, contact us in advance. Use in varying load applications (precession motion, etc.) might result in product failures.

Maintenance

- 66. Perform maintenance or inspection with great care since servo motor frames become very hot. Failure to follow this may result in a burn.
- 67. Servo motor's oil seals, holding brakes, bearings, and brushes (for DC servo motors only) are life-limited parts. Determine when to replace them based on the results of the actual equipment evaluation.
- Contact us or your point of sale for repair. Disassembling the product by yourself may end up causing more damage.

Transportation

- 69. Transport the motor with great care to avoid the risk of it falling or tipping over.
- 70. Do not hold it by the motor output shaft or cable during transportation. Doing so may cause product damage or injury.

OPROHIBITED

Storage

 Avoid storing products in environments exposed to rain or water drops or with hazardous gas or liquid. Failure to follow this may cause product failures.

Maintenance

- 72. Do not disassemble or repair the product. Doing so may cause fire or an electric shock.
- Do not measure the insulation resistance or dielectric strength of the motor by yourself. Failure to follow this may cause product damage.

General

- 74. Do not remove the nameplate. Using motors with incorrect ratings may result in fire.
- 75. Do not apply static electricity or high voltage to the encoder cable. Failure to follow this may cause product failures.

Operation

76. The brake built into servo motors is a holding brake and must not be used for dynamic braking. Doing so may reduce brake torque, cause burnout, or accelerate brake wear, resulting in product failures.

MANDATORY

Storage

- Store the product out of direct sunlight within the specified temperature and humidity ranges.
- 78. Contact us before using a servo motor that has been stored for a long period (roughly 3 years or longer). Checking on bearings and brakes will be needed.

Operation

- Install an emergency stop circuit to the outside of equipment to turn the power off immediately whenever needed.
- 80. Operate the motor within the specified ambient temperature and humidity ranges.
- When operating servo motors with a cooling fan, be sure to use the cooling fan. Failure to follow this may cause fire or product failures.

Transportation

 Avoid overstacking and stack boxes in compliance with the instructions given on the outside of the package to prevent collapse.

Disposal

83. Dispose of servo motors as general industrial waste.

Safety Precautions

- Read the accompanying Instruction Manual carefully prior to using the product.
- Do not use this product in an environment where vibration is present, such as in moving vehicles or shipping vessels.
- Do not perform any retrofitting, re-engineering, or modification to the product.

Please contact us beforehand if you intend to use this product in the following applications.

- Medical equipment that may have an effect on human life
- Systems or equipment that may have a major impact on society or on the public
- Special applications related to aviation and space, nuclear power, electric power, submarine repeaters, etc.

SANYO DENKI CO., LTD. 3-33-1 Minami-Otsuka, Toshima-ku, Tokyo 170-8451, Japan TEL: +81 3 5927 1020 https://www.sanyodenki.com

The names of companies and/or their products specified in this catalog are the trade names, and/or trademarks and/or registered trademarks of such respective companies.
SANMOTION is a trademark of SANYO DENKI CO., LTD.
Specifications are subject to change without notice.
CATALOG No. S1052B003 '22.9