Metering Valve with Silencer

Series ASN2



Superior sound reducing performance

Over 20 dB at max. flow rate

Cylinder speed easily set

Shape of needle is the same as that of speed controller

Retainer prevents accidental loss of needle



JIS Symbol



<Example of mounting>



Model


Model	Port size	Effective area (mm²)	Mass (g)
ASN2-M5	M5 x 0.8	1.8	5
ASN2-U10/32	10-32 UNF	1.8	5
ASN2-01	1/8	3.6	17
ASN2-02	1/4	6.5	34
ASN2-03	3/8	16.6	55
ASN2-04	1/2	24.5	107

Specifications


Proof pressure	1.5 MPa		
Operating pressure range	0 to 1 MPa		
Ambient and fluid temperature	- 5 to 60°C (No freezing)		
Number of needle rotations	10 turns (8 turns Note))		

Note) () is the case of ASN2-M5 and ASN2-U10/32.


How to Order



Needle Valve/Flow Characteristics




Construction



Component Parts

No.	Description	Material	Note
1	Handle	PBT	
2	Needle	Brass	Electroless nickel plated
3	Lock nut	Steel	Zinc chromated
4	Needle guide	Brass	Electroless nickel plated
5	Washer	Carbon steel	Nickel plated
6	O-ring	NBR	
7	Silencer	PVA sponge	
8	Silencer cover	Soft polyethlene	
9	Body B	Brass	Electroless nickel plated
10	Gasket	NBR/Stainless steel	M5, U10/32 only

Dimensions



Dimensions

Model	Screw D	øD	L1 ⁽²⁾		н
iviodei			Min.	Max.	
ASN2-M5	M5 x 0.8	10	20.5	23.3	8
ASN2-U10/32	10-32 UNF	10	20.5	23.3	8
ASN2-01	1/8	15	29.1	34.1	12 (12.7)
ASN2-02	1/4	20	33.7	38.7	17 (17.5)
ASN2-03	3/8	25	35.9	40.9	19
ASN2-04	1/2	30	48.1	53.1	24 (23.8)

Note 1) (in parentheses) are the dimensions of "NPT" screw specifications.

Note 2) L1: Reference dimensions

Specific Product Precautions

Be sure to read before handling.


Refer to front matters 58 and 59 for Safety Instructions and pages 412 to 414 for Flow Control Equipment Precautions.

Selection

⚠Warning


1. Example of inapplicable circuits

(a) Perfect Valve (VF66□□, VS7-6-FPG, VS7-8-FPG)



Residual pressure behind the exhaust needle may cause check valve malfunction in the Perfect Valve.

(b) Pilot check valve between Actuator and Valve



Residual pressure behind the exhaust needle may cause pilot check valve malfunction.

Installation

.Marning

installing flow controls to valve ports, interference may occur with the fittings. Please consult the catalog before installing.




Fig. Example of the interference with fittings

AS

ASP

ASN

AQ

ASV

AK

VCHC

ASS

ASR ASQ

KE

TMH