

# Parallel Type Air Gripper

# MHZ Series

ø6, ø10, ø16, ø20, ø25, ø32, ø40




# Integral linear guide used for high rigidity



Martensitic stainless steel ------


#### High degree of mounting flexibility


Can be mounted five ways from three directions.



## Body option/Piping port location

#### Finger positions can be selected. (Standard type/MHZ2)





382

**SMC** 

# and high precision

Integral

construction

guide rail

- Body thickness tolerance: ±0.05 mm
- No guide protrusion in direction of body thickness
- Dimproved remounting accuracy Positioning dowel pin holes provided
- Top mounting centering location Mounting is more secure with a depth 0.5 to 2 mm greater than current types.



#### **Cover materials**

- · Chloroprene rubber (Black)
- · Fluororubber (Black)
- · Silicone rubber (White)

#### Made to Order

- · Dust cover adhesion (Powerful adhesive used): -X77
- · Dust cover caulking (Silicone caulking agent used): -X78

ø32. ø40

Made to Order

Page 451

**⊘**SMC

ø6

383

D-

Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

ø10 to ø25

# Parallel Type Air Gripper *MHZ2* Series Series Variations

			Basic type End boss type						
			Side ported	Side ported	With One-touch fitting for	With One-touch fitting	With M3 port	With M5 port	
					coaxial tubing				
					(E)		(甲)	日	
Series	Bore size (mm)	Action	ſŢŢ	0 0	0 0	0 0	0 0	0 0	
		Double acting	•	•					
Standard	6	Single acting (Normally open)	•	•		•	•		
MHZA2-6 Page 398		Single acting (Normally closed)	•	•		•	•		
		Double acting	•	•					
With dust cover	6	Single acting	•	•		•	•		
MHZAJ2-6 Page 398		(Normally open) Single acting (Normally closed)	•	•		•	•		
					I				
		Double acting Single acting	•						
	6	(Normally open)	•						
1. m		Single acting (Normally closed)	•						
Standard	10, 16 20, 25	Double acting Single acting	•	•	•				
MHZ2 Page 408		(Normally open) Single acting	•	•		•		•	
		(Normally closed)	•	•		•		•	
A REAL	32, 40	Double acting	•						
		Single acting (Normally open)	•						
		Single acting (Normally closed)	•						
Long stroke	10.10	Double acting	•	•	•				
MHZL2	10, 16 20, 25	Single acting (Normally open)	•	•		•		•	
Page 426		Single acting (Normally closed)	•	•		•		•	
Long stroke With dust cover MHZL2 Page 436	10, 16 20	Double acting	•						
11		Double acting	•						
A sea	6	Single acting (Normally open)	•						
With dust cover MHZJ2		Single acting (Normally closed)	•						
Page 440		Double acting	•	•	•				
Page 451	10, 16 20, 25	Single acting (Normally open)	•	•		•		•	
		Single acting (Normally closed)	•	•		•		●	
	32, 40	Double acting	•						


384

**⊘**SMC

	er option				
With hose nipple Basic type (tapped in open/close direction) Side tappe	d Through-holes in open/close direction	Flat type finger			
			Made to Order common specifications	Page	
	•	•			
• • •	•	•			
•				Page 398	
• •					
• •	1		* Availability varies depending on the model.		
	•	•	For details, refer to "Made to Order" on pages 725 to 748.		
	•	•	-X4 Heat resistance (-10 to 100 °C)		MHZ
• •	•	•	-X5 Fluororubber seal		MHF
	•	•	-X7         Closing direction spring assist           -X12         Opening direction spring assist		
• •	•	•	-X46 Built-in needle valve for finger speed control -X50 Without magnet	Page 408	MHL
• •	•	•	-X51 MHQ2/MHQG2 compatible flat type fingers		MHR
• •	•	•	-X53         Ethylene propylene rubber seal (EPDM)           -X56         Axial ported		MHK
• •	•	•	-X63 Fluorine grease -X64 Finger: Side tapped		MHS
• •	•	•	-X65 Finger: Through-holes in opening/closing		MHC
	•	•	directions -X77A Dust cover adhesion		МНТ
• •	•	•	-X77B Dust cover adhesion/Finger part only -X78A Dust cover caulking	Page 426	МНҮ
• •	•	•	-X78B Dust cover caulking/Finger part only -X79 Grease for food processing machines/Fluorine		
			grease		MHW
			-X79A Grease for food processing machines/ Aluminum complex soap base grease	Page 436	-X□
			-X81A Special black chromium treatment is made on only the finger.		MRHQ
•	_		-X81B Special black chromium treatment is made on		MA
•			the finger and guide.		D-🗆
				Page 440	
•					
•					
•				Page 451	

# MHZ Series **Model Selection**


## Model Selection



Model Selection Illustration When gripping a workpiece as in the figure to the left, and with the following definitions, F: Gripping force (N) u: Coefficient of friction between the attachments and the workpiece ¢ m: Workpiece mass (kg) g: Gravitational acceleration (= 9.8 m/s<sup>2</sup>) mg: Workpiece weight (N) the conditions under which the workpiece will пE not drop are mg  $2 \times \mu F > mg$ "Gripping force at least 10 to 20 times the workpiece weight" Number of fingers The "10 to 20 times or more of the workpiece weight" recommended by SMC is calculated with a safety margin of a = 4, which allows for impacts that occur during normal transportation, etc. and therefore, When  $\mu = 0.2$ When  $\mu = 0.1$ mg F > -**2 x** μ mq mg  $\mathbf{F} = \mathbf{v}$ – x 4 x 4 2 x 0.2 2 x 0.1 With "a" representing the extra margin, = 10 x ma "F" is determined by the following formula: = 20 x mg mg F = ----— ха **2 x** μ 10 x Workpiece weight 20 x Workpiece weight Note) • Even in cases where the coefficient of friction is greater than  $\mu = 0.2$ , for reasons of safety, select a gripping force which is at least 10 to 20 times

greater than the workpiece weight, as recommended by SMC. • If high acceleration, deceleration or impact forces are encountered during motion, a further margin of safety should be considered.

@SMC



387


# MHZ Series

## Model Selection


## Step 1 Effective Gripping Force: MHZ 2 Series/Double Acting/Internal Gripping Force -----


Internal Gripping Force


 Indication of effective gripping force The effective gripping force shown in the graphs to the right is expressed as F, which is the thrust of one finger, when both fingers and attachments are in full contact with the workpiece as shown in the figure below.





Internal Grip















388

**SMC** 




# MHZ Series


#### **Model Selection**


# Step 1 Effective Gripping Force: MHZD2 Series/Single Acting/Internal Gripping Force


 Indication of effective gripping force
 The effective gripping force shown in the graphs to the right is expressed as F, which is the thrust of one finger, when both fingers and attachments are in full contact with the workpiece as shown in the figure below.




Internal Grip









**SMC** Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

Gripping point L (mm)

0.2 MPa


# MHZ Series

## **Model Selection**


## Step 1 Effective Gripping Force: MHZ 2 Series/Double Acting/Internal Gripping Force ----


Internal Gripping Force


Internal Gripping Force





Internal Grip











392

Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

#### **External Gripping Force External Gripping Force** · Indication of effective gripping force MHZJ2-6S/MHZAJ2-6S MHZJ2-25S The effective gripping force shown in the graphs to the right is expressed as F, which is the thrust of one finger, when both fingers and attach-80 Pressure 0.7 MPa ments are in full contact with the workpiece as Pressure 0.7 MPa shown in the figure below. ŝ ŝ 60 0.6 MPa 3 Gripping force Gripping force 0.6 MPa 0.5 MPa 4 2 0.5 MPa 40 0.4 MPa 0.4 MPa 20 0.3 MPa 0.3 MPa 0.25 MPa 0 30 0 20 40 60 20 Gripping point L (mm) Gripping point L (mm) **External Grip MHZJ2-10S** MHZAJ2, MHZJ2 12 Pressure 0.7 MPa 10 ¢ 0.6 MPa ŝ ۶ Gripping force 0.5 MPa ÷ 6 the 0.4 MPa 4 0.35 MPa 2 0 20 30 50 60 10 40 Gripping point L (mm) MHZJ2-16S

MHF
MHL
MHR
MHK
MHS
MHC
MHT
MHY
MHW
-X□
MRHQ
MA
D-🗆

MHZ

Step 1 Effective Gripping Force: MHZ 2 Series/Single Acting/External Gripping Force -

80

100

Pressure 0.7 MPa 40 0.6 MPa ŝ 30 Gripping force 0.5 MPa 20 0.4 MPa 0.3 MPa 10 0.25 MPa 0 10 20 30 40 50 60 Gripping point L (mm) MHZJ2-20S 50 Pressure 0.7 MPa 40 0.6 MPa ŝ force 30 0.5 MPa Gripping 20 0.4 MPa 0.3 MPa 10 0.25 MPa 0 40 80 20 60 100 Gripping point L (mm) **SMC** 


393

# MHZ Series


#### **Model Selection**


## Step 1 Effective Gripping Force: MHZ 2 Series/Single Acting/Internal Gripping Force

 Indication of effective gripping force
 The effective gripping force shown in the graphs to the right is expressed as F, which is the thrust of one finger, when both fingers and attachments are in full contact with the workpiece as shown in the figure below.




Internal Grip






### Internal Gripping Force



MHZJ2-10C Pressure 0.7 MPa 20 0.6 MPa ŝ 15 Gripping force 0.5 MPa 10 0.4 MPa 0.35 MPa 5 0 10 20 30 40 50 Gripping point L (mm) MHZJ2-16C 60 50 Pressure 0.7 MPa ŝ 0.6 MP 40 force 0.5 MP 30 Gripping . 0.4 MPa 20 0.3 MPa 10 0.25 MPa 0 50 60 20 30 40 Gripping point L (mm) MHZJ2-20C Pressure 0.7 MPa Î 0.6 MPa force 60 0.5 MPa Gripping 0.4 MPa 40 0.3 MPa 20 0.25 MPa 100 0 40 80 Gripping point L (mm)

#### 394




#### 395

# MHZ Series


## **Model Selection**


## Step 2 Confirmation of Gripping Point: MHZ

#### Internal Grip




- The air gripper should be operated so that the workpiece gripping point "L" and the amount of overhang "H" stay within the range shown for each operating pressure given in the graphs to the right.
- If the workpiece gripping point goes beyond the range limits, this will have an adverse effect on the life of the air gripper.









L: Distance to the point at which the load is applied (mm)

		Maximum allowable moment					
Model	Allowable vertical load Fv (N)	Pitch moment: Mp (N·m)	Yaw moment: <b>My</b> (N·m)	Roll moment: <b>Mr</b> (N⋅m)			
MHZ□2-6	10	0.04	0.04	0.08			
MHZ□2-10	58	0.26	0.26	0.53			
MHZ□2-16	98	0.68	0.68	1.36			
MHZ□2-20	147	1.32	1.32	2.65			
MHZ□2-25	255	1.94	1.94	3.88			
MHZ□2-32	343	3	3	6			
MHZ□2-40	490	4.5	4.5	9			
late) Values for lead and moment in the table indicate static values							

Note) Values for load and moment in the table indicate static values.

When a static load of f = 10 N is operating, which applies pitch moment to point L = 30 mm from the MHZ $\square$ 2-16D guide. Therefore, it can be used. Allowable load F = $\frac{0.68}{30 \times 10^{-3}}$ = 22.7 (N) Load f = 10 (N) < 22.7 (N)

MHZ
MHF
MHL
MHR
MHK
MHS
MHC
MHT
MHY
MHW
-X□
MRHQ
MA
<b>D-</b> □

# Parallel Type Air Gripper (Standard) Compact Series (Without Auto Switch) MHZA2-6/MHZAJ2-6 Series

How to Order MHZA 6 2 MHZAJ 2 6 Made to Order Refer to page 399 for details. With dust cover Dust cover type Nil Chloroprene rubber (CR) Number of fingers Fluororubber (FKM) F 2 2 fingers S Silicone rubber (Si) Bore size Body option 6 6 mm Nil: Basic type E: End boss type K: End boss type Port Side ported Axial ported Action (Double acting/Single acting) with ø4 One-touch fitting D Double acting (Single acting) S Single acting (Normally open) Port C Single acting (Normally closed) Port Finger option Ø [Standard] 1 Nil: Basic type Port Port H: End boss type M: End boss type 1: Side tapped mounting Axial ported Axial ported with ø4 hose nipple with M3 port (Single acting) (Single acting) Ø 2: Through-holes in opening/closing direction 3: Flat type fingers

Specifications								
Fluid Air								
Operating Double acting		0.15 to 0.7 MPa						
Single	Normally open	0.3 to 0.7 MPa						
acting	Normally closed	0.3 to 0.7 MFa						
d fluid ter	nperature	-10 to 60°C						
ty		±0.01 mm						
ting frequ	ency	180 c.p.m.						
1		Not required						
		Double acting/Single acting						
	Flu Doubl Single acting Id fluid ter ty ting freque	Fluid Double acting Single Normally open acting Individual temperature ty ting frequency						

\* Use the gripper with dust cover when used in a place where there may be dust.

#### Model

			-	Gripping f	Opening/		
			Bore	Gripping for	Gripping force per finger		Weight
Actio	n	Model	size (mm)	Effective	Closing (Both sides)	(g)	
				External	Internal	(mm)	
Doub	le	MHZA2-6D	6	3.3	6.1	4	26
acting	3	MHZAJ2-6D	6			4	27
	Normally open	MHZA2-6S	6	1.9		4	26
Single	Norn	MHZAJ2-6S	6	1.5	_	4	27
acting	acting MHZA2-6C 6 MHZAJ2-6C 6	MHZA2-6C 6	6		3.7	4	26
Norm		6	_	3.7	4	27	

Note) Values based on pressure of 0.5 MPa, gripping point L = 20 mm, at center of stroke.

#### Option

#### Body Option/End Boss Type

	,	-76-			- P
Symbol Piping port location		Type of piping port	Applicat	ole model	ľ
Symbol	Piping port location	MHZA2-6/MHZAJ2-6	Double acting	Single acting	
Nil	Basic type	M3 x 0.5	•		ľ
E	Side ported	M3 x 0.5	•	•	
к		With ø4 One-touch fitting	—		ſ
н	Axial ported	With ø4 hose nipple	—	•	
М		M3 x 0.5	—		ſ

MHZ

```
MA
D-🗆
```

When operating an actuator with a small diameter and a short stroke at a high frequency, the dew condensation (water droplet) may occur inside the piping depending on the conditions. Simply connecting the moisture control tube to the

actuator will prevent dew condensation from occurring. For details, refer to the IDK series in the **Best Pneumatics No. 6** 

#### Symbol

Double acting: Internal grip



Double acting: External grip



Single acting/ Normally closed: Internal grip



Single acting/ Normally open: External grip



#### Made to Order Click here for details


Symbol	Specifications/Description
-X4	Heat resistance (100°C)
-X5	Fluororubber seal
-X12	Opening direction spring assist
-X53	EPDM seal/Fluorine grease
-X56	Axial ported type
-X63	Fluorine grease
-X64	Finger: Side tapped mounting
-X65	Finger: Through-hole mounting
-X79	Grease for food processing machines, Fluorine grease
-X79A	Grease for food processing machines
-X81A	Anti-corrosive treatment of finger
-X81B	Anti-corrosive treatment of finger and guide

Moisture


# MHZA2-6/MHZAJ2-6 Series

## **Construction: Standard Type MHZA2-6**

#### Double acting/With fingers open



#### Double acting/With fingers closed



## **Component Parts**

	-p		
No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Piston	Stainless steel	
3	Lever	Stainless steel	Heat treated
4	Guide	Stainless steel	Heat treated
5	Finger	Stainless steel	Heat treated
6	Roller stopper	Stainless steel	
7	Lever shaft	Stainless steel	Nitriding
8	Holder	Brass	Electroless nickel plated
9	Holder lock	Stainless steel	
10	Сар	Aluminum alloy	Clear anodized
11	Bumper	Urethane rubber	
12	Steel balls	High carbon chrome bearing steel	
13	Needle roller	High carbon chrome bearing steel	

#### **Component Parts**

Description	Material	Note
Type C retaining ring	Carbon steel	Phosphate coated
Exhaust plug	Brass	Electroless nickel plated
Exhaust filter	Polyvinyl formal	
N.O. spring	Stainless steel spring wire	
N.C. spring	Stainless steel spring wire	
N.C. holder	Brass	Electroless nickel plated
N.C. spacer	Stainless steel	
Rod seal	NBR	
Piston seal	NBR	
Gasket	NBR	
Gasket	NBR	
	Type C retaining ring Exhaust plug Exhaust filter N.C. spring N.C. holder N.C. spacer Rod seal Piston seal Gasket	Type C relaining ring         Carbon steel           Exhaust plug         Brass           Exhaust filter         Polyvinyl formal           N.O. spring         Stainless steel spring wire           N.C. holder         Brass           N.C. spacer         Stainless steel           Rod seal         NBR           Piston seal         NBR           Gasket         NBR

#### **Replacement Parts**

Desci	ription	MHZA2-6	Main parts				
Finger assembly		Please contact SMC to replace the seal kit and finger assembly.					
	MHZA2-6□□H	MHZA-A0607					
End boss assembly	MHZA2-6□□K	MHZA-A0608	Main body of adaptor Mounting screw for adaptor				
End boss assembly	MHZA2-6□□M	MHZA-A0609	Seal				
	MHZA2-6□□E	MHZA-A0610					


\* The end boss assembly other than type E should be mounted on the special body.

Replacement part/Grease pack part no.: GR-S-010 (10 g)


#### 400

# **SMC**

# Single acting/Normally open




#### Single acting/Normally closed




## Construction: With Dust Cover MHZAJ2-6


#### Double acting/With fingers open




#### Double acting/With fingers closed



#### Single acting/Normally open



#### Single acting/Normally closed



#### **Component Parts** Description

No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Piston	Stainless steel	
3	Lever	Stainless steel	Heat treated
4	Guide	Stainless steel	Heat treated
5	Finger	Stainless steel	Heat treated
6	Roller stopper	Stainless steel	
7	Lever shaft	Stainless steel	Nitriding
8	Holder	Brass	Electroless nickel plated
9	Holder lock	Stainless steel	
10	Сар	Aluminum alloy	Clear anodized
11	Bumper	Urethane rubber	
12	Steel balls	High carbon chrome bearing steel	
13	Needle roller	High carbon chrome bearing steel	

#### **Component Parts**

No.	Description	Material	Note
		CR	Chloroprene rubber
14	Dust cover	FKM	Fluororubber
		Silicone rubber	
15	Type C retaining ring	Carbon steel	Phosphate coated
16	Exhaust plug	Brass	Electroless nickel plated
17	Exhaust filter	Polyvinyl formal	
18	N.O. spring	Stainless steel spring wire	
19	N.C. spring	Stainless steel spring wire	
20	N.C. holder	Brass	Electroless nickel plated
21	N.C. spacer	Stainless steel	
22	Rod seal	NBR	
23	Piston seal	NBR	
24	Gasket	NBR	
25	Gasket	NBR	

#### **Replacement Parts**

Desc	riptio	n	MHZAJ2-6	Main parts
Seal kit			Please contact SMC to re	place the seal kit.
	ial	CR	MHZAJ2-J6	
Dust cover	ē	FKM	MHZAJ2-J6F	14
	Ma	Silicone rubber	MHZAJ2-J6S	
Finger assembly			Please contact SMC to re	place the finger assembly.
	1	MHZA2-6□□H	MHZA-A0607	
End boss assembly	1	MHZA2-6□□K	MHZA-A0608	Main body of adaptor Mounting screw for adaptor
End boss assembly	N	//HZA2-6□□M	MHZA-A0609	Seal
	1	MHZA2-6□□E	MHZA-A0610	oour

....

\* End boss type

H = With hose nipple, K = With One-touch fitting, M = With M3 port, E = Side ported

\* The end boss assembly other than type E should be mounted on the special body.


Replacement part/Grease pack part no.: GR-S-010 (10 g)




# MHZA2-6/MHZAJ2-6 Series

## **Dimensions: Standard Type**

# MHZA2-6 Double acting/Single acting Basic type







\* For single action, the port on one side is a breathing hole.

# Parallel Type Air Gripper/Compact Series MHZA2-6/MHZAJ2-6 Series

#### **Dimensions: With Dust Cover**





\* For single action, the port on one side is a breathing hole.

MHY MHW -X□ MRHQ MA D-🗆

403

MHZ

MHF

MHL

MHR MHK


MHS

MHC

MHT


# MHZA2-6 Series Finger Option

## Side Tapped Mounting [1]




\* Specifications and dimensions other than the above are the same as the basic type.

## Through-holes in Opening/Closing Direction [2]



 $\ast$  Specifications and dimensions other than the above are the same as the basic type.

## Flat Type Fingers [3]




# MHZA2-6/MHZAJ2-6 Series Body Option: End Boss Type

## Applicable Model

Symbol	Dising part leastion	Type of p	iping port	Applicab	le model
Symbol	Piping port location	MHZA2	MHZAJ2	Double acting	Single acting
E	Side ported	M3 >	¢ 0.5	•	•
н		With ø4 h	ose nipple	_	•
к	Axial ported	With ø4 One	-touch fitting	_	•
М	•	M3 >	¢ 0.5	_	•

## Side Ported [E]


#### MHZA2-6 🗆 🗆 E




\* Specifications and dimensions other than the above are the same as the basic type.

## Axial Ported (with hose nipple) [H]

#### MHZA2-6°C□H




\* Specifications and dimensions other than the above are the same as the basic type.



 Specifications and dimensions other than the above are the same as the basic type or the end boss dimensions of the MHZA type.

#### MHZAJ2-6<sup>s</sup>H□

MHZAJ2-6



 Specifications and dimensions other than the above are the same as the basic type or the end boss dimensions of the MHZA type.

#### Applicable Tubing

Des	scription/	Nylon tubing	Soft nylon tubing	Polyurethane tubing	Polyurethane coil tubing
Specifications	Model	T0425	TS0425	TU0425	TCU0425B-1
Outside diameter (mm)		4	4	4	4
Max. operating pressure	(MPa)	1.0	0.8	0.5	0.5
Min. bending radius (mr	n)	13	12	10	—
Operating temperature	(°C)	-20 to 60	-20 to 60	-20 to 60	-20 to 60
Material		Nylon 12	Nylon 12	Polyurethane	Polyurethane

Refer to "Pneumatic Piping Equipment (CAT. E50)" regarding One-touch fittings and tubing.



MHZ

MHF

MHR

МНК

MHS

MHC

MHT

MHY

MHW

-X□

MRHQ Ma


D-🗆

# MHZA2-6/MHZAJ2-6 Series

## Axial Ported (with One-touch fitting) [K]

## MHZA2-6 cS□K

#### MHZAJ2-6<sup>s</sup><sub>c</sub>K



\* Specifications and dimensions other than the above are the same as the basic type.

\* Specifications and dimensions other than the above are the same as the basic type or the end boss dimensions of the MHZA type.


#### Applicable Tubing

Description/	Nylon tubing	Soft nylon tubing	Polyurethane tubing	Polyurethane coil tubing
Specifications	T0425	TS0425	TU0425	TCU0425B-1
Outside diameter (mm)	4	4	4	4
Max. operating pressure (MPa)	1.0	0.8	0.5	0.5
Min. bending radius (mm)	13	12	10	_
Operating temperature (°C)	-20 to 60	-20 to 60	-20 to 60	-20 to 60
Material	Nylon 12	Nylon 12	Polyurethane	Polyurethane


Refer to "Pneumatic Piping Equipment (CAT. E50)" regarding One-touch fittings and tubing.

## Axial Ported (with M3 port) [M]

#### MHZA2-6<sup>s</sup>⊡M



\* Specifications and dimensions other than the above are the same as the basic type.




MHZAJ2-6<sup>s</sup><sub>c</sub> M□

\* Specifications and dimensions other than the above are the same as the basic type or the end boss dimensions of the MHZA type.

## Weight

				(g)
Model		End boss ty	pe (Symbol)	
woder	E	н	к	М
MHZA2-6	28	28	28	28
MHZAJ2-6	29	29	29	29

# Parallel Type Air Gripper/Standard Type MHZ2 Series ø6, ø10, ø16, ø20, ø25, ø32, ø40



Applicable Auto Switches/Refer to pages 797 to 850 for further information on the auto switch.

	Original	Els states i	Indiantar	Marine an	,	oad volta	00	Auto swit	ch model	Lead	d wire I	ength	(m) *									
Туре	Special function	entry	Indicator light	Wiring (Output)	'	Load voltage		Load voltage		Load voltage		Louid Voltage		Electrical en	try direction	0.5	1	3	5	Pre-wired connector		cable ad
	lanotion	onay	light	(Output)		DC	DC AC		In-line	(Nil)	(Nil) (M)	(L)	(Z)	0011100101		au						
				3-wire (NPN)				M9NV	M9N	٠	•	٠	0	0								
				3-wire (INPIN)		5 V. 12 V		F8N	—	٠	-	٠	0	-	IC							
_						5 V, 12 V		M9PV	M9P	•	•	•	0	0	circuit							
switch	_			3-wire (PNP)				F8P	_	٠	-	٠	0	-								
NS C				2-wire		12 V		M9BV	M9B	٠	•	٠	0	0								
auto		Grommet	Yes	2-wire	24 V	12 V		F8B	_	•	-	•	0	-	_	Relay,						
state	Diagnosis	Grommet	res	3-wire (NPN)	24 V	5 V. 12 V	_	M9NWV	M9NW	٠	•	٠	0	0	IC	PLC						
	(2-color			3-wire (PNP)		5 V, 12 V		M9PWV	M9PW	٠	•	٠	0	0	circuit							
Solid	indicator)			2-wire		12 V		M9BWV	M9BW	٠	•	٠	0	0	-							
0	Water resistant			3-wire (NPN)		5 V, 12 V		M9NAV**	M9NA**	0	0	٠	0	0	IC							
	(2-color			3-wire (PNP)		5 V, 12 V		M9PAV**	M9PA**	0	0	٠	0	0	circuit							
	indicator)			2-wire		12 V		M9BAV**	M9BA**	0	0	٠	0	0	-							

\*\* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance. \* Lead wire length symbols: 0.5 m ..... Nil (Example) M9NW

\* Solid state auto switches marked with O are produced upon receipt of order.

1 m ..... M (Example) M9NWM

3 m ..... L (Example) M9NWL


5 m ...... Z (Example) M9NWZ

Note 1) When using a D-F8<sup>-</sup> switch, mount it at a distance of 10 mm or more from magnetic substances such as iron, etc.

Note 2) When using the 2-color indicator type, please make the setting so that the indicator is lit in red to ensure the detection at the proper position of the air gripper.

# Parallel Type Air Gripper/Standard Type MHZ2 Series

How to Order



	Creation			Marine an	L L	oad voltad	or	Auto swit	ch model	Leau	wire	engui	(111)	Abb	iicau	ie ind	Juei	Description of	Annlie	able
Туре	Special function	Electrical entry	Indicator light	Wiring (Output)		ວລິດ ຈົບແລຍູ	Je	Electrical en	try direction	0.5	1	3	5	ø10	a16	~ ~ ~ ~		Pre-wired connector		
		onay	ingin	(Output)		DC	AC	Perpendicular	In-line	(Nil)	(M)	(L)	(Z)	010	010	620	025			
								M9NV	M9N	٠	•	•	0	•	•	٠	•	0		
				3-wire (NPN)	1	5 V. 12 V		F8N		٠	-	•	0	-	•	٠	•	-	IC	
6	_			3-wire (PNP)	]	5 V, 12 V		M9PV	M9P	٠	•	٠	0	•	•	٠	•	0	circuit	
switch	_			3-wire (PINP)				F8P	_	٠	-	٠	0	-	٠	٠	•	-		
l s c				2-wire	]	12 V		M9BV	M9B	٠	•	•	0	•	•	٠	•	0		
auto		Grommet	Yes	2-wire	24 V	12 V		F8B		٠	-	•	0	-	•	٠	•	-	_	Relay,
state	Diagnosis	aronnier	ies	3-wire (NPN)		5 V. 12 V	-	M9NWV	M9NW	٠	•	٠	0	•	٠	٠	٠	0	IC	PLC
	(2-color			3-wire (PNP)	]	5 V, 12 V		M9PWV	M9PW	٠	•	•	0	•	•	٠	•	0	circuit	
Solid	indicator)			2-wire	]	12 V		M9BWV	M9BW	٠	•	•	0	•	•	٠	•	0	-	
0	Water resistant			3-wire (NPN)	]	5 V. 12 V		M9NAV**	M9NA**	0	0	٠	0	•	•	٠	•	0	IC	
	(2-color			3-wire (PNP)	]	5 V, 12 V		M9PAV**	M9PA**	0	0	٠	0	•	•	٠	•	0	circuit	
	indicator)			2-wire	]	12 V		M9BAV**	M9BA**	0	0	٠	0	•	•	٠	•	0	-	

\*\* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot quarantee water resistance \* Solid state auto switches marked with

- \* Lead wire length symbols: 0.5 m ..... Nil (Example) M9NW 1 m ..... M (Example) M9NWM
  - 3 m ..... L (Example) M9NWL
  - 5 m ..... Z (Example) M9NWZ

O are produced upon receipt of order.

#### Moisture Control Tube **IDK Series**

When operating an actuator with a small diameter and a short stroke at a high frequency, the dew condensation (water droplet) may occur inside the piping depending on the conditions.

Simply connecting the moisture control tube to the actuator will prevent dew condensation from occurring. For details, refer to the IDK series in the Best Pneumatics No. 6.

Note 1) When using the 2-color indicator type, please make the setting so that the indicator is lit in red to ensure the detection at the proper position of the air gripper. Note 2) Through-hole mounting is not possible when using the auto switch at the square groove on the side.


Note 3) When the product is ordered with auto switch, only MHZ2-10 is shipped with the auto switch mounting brackets. When the auto switch is used at the square groove on the side with MHZ2-16 to 25, mounting brackets (BMG2-012) are required. Pease order them separately. Refer to page 457 for the auto switch mounting brackets.

# **SMC**

Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

MHT MHY MHW -X□ MRHO MA D-

# MHZ2 Series



#### Annlicable Auto Switches/Refer to pages 797 to 850 for further information on the auto switch

								Auto swit	ch model	Lead	wire le	ength	(m) *			
Гуре	Special function	Electrical entry	Indicator light	Wiring (Output)	Load voltage		Э	Electrical en	try direction	0.5	1	3	5	Pre-wired connector	Applie	cable ad
	Turiotion	entry	iigin	(Output)	I	DC DC	AC	Perpendicular	In-line	(Nil)	(M)	(L)	(Z)	CONTINUEDIDI	10	au
				3-wire (NPN)				M9NV	M9N	•	•	٠	0	0		
				S-wire (INPIN)		5 V. 12 V		F8N	_	•	-	٠	0	-	IIC	
c				3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	٠	0	0	circuit	
switch	_			S-WIE (FINF)				F8P	—	•	-	٠	0	-		
o sv				2-wire		12 V		M9BV	M9B	•	•	٠	0	0		
auto		0		2-wire	24 V	12 V		F8B	_	•	-	٠	0	_	-	Relay
state	Diagnosis	Grommet	Yes	3-wire (NPN)	24 V	5 V. 12 V	_	M9NWV	M9NW	•	٠	٠	0	0	IC	PLC
l sta	(2-color			3-wire (PNP)		5 V, 12 V		M9PWV	M9PW	•	•	٠	0	0	circuit	
Solid	indicator)			2-wire		12 V		M9BWV	M9BW	•	•	٠	0	0	-	1
0	Water resistant			3-wire (NPN)		5 V. 12 V		M9NAV**	M9NA**	0	0	٠	0	0	IC	1
	(2-color			3-wire (PNP)		5 V, 12 V		M9PAV**	M9PA**	0	0	٠	0	0	circuit	
	indicator)			2-wire		12 V		M9BAV**	M9BA**	0	0	•	0	0	_	1

\*\* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance. \* Solid state auto switches marked with O are produced upon receipt of order.


\* Lead wire length symbols: 0.5 m ..... Nil (Example) M9NW 1 m······ M (Example) M9NWM

- 3 m······ L (Example) M9NWL 5 m······ Z (Example) M9NWZ

Note 1) When using the 2-color indicator type, please make the setting so that the indicator is lit in red to ensure the detection at the proper position of the air gripper. Note 2) Through-hole mounting is not possible when using the auto switch at the square groove on the side.

Note 3) When the auto switch is used at the square groove on the side with MHZ2-32 and 40, mounting brackets (BMG2-012) are required. Please order them separately. Refer to page 457 for the auto switch mounting brackets.

# Parallel Type Air Gripper/Standard Type MHZ2 Series



Axial ported type

Fluorine grease

Grease for food processing machines, Fluorine grease

Grease for food processing machines

Anti-corrosive treatment of finger -X81B Anti-corrosive treatment of finger and guide

-X56 -X63

-X79

-X79A

-X81A

## Specifications

	Fluid		Air
			ø6: 0.15 to 0.7 MPa
	Dou	ble acting	ø10: 0.2 to 0.7 MPa
Operating	· · · · · · · · · · · · · · · · · · ·		ø16 to ø40: 0.1 to 0.7 MPa
pressure	Single	Normally open	ø6: 0.3 to 0.7 MPa
	acting		ø10: 0.35 to 0.7 MPa
		Normally closed	ø16 to ø40: 0.25 to 0.7 MPa
Ambient a	nd fluid	temperature	-10 to 60°C
Repeatabi	lity		ø6 to ø25: ±0.01 mm
переатар	iity		ø32, ø40: ±0.02 mm
Max oper	otina fra	guopov	ø6 to ø25: 180 c.p.m.
Max. oper	Max. operating frequency		ø32, ø40: 60 c.p.m.
Lubrication			Not required
Action			Double acting/Single acting
Auto switch (Option) Note)			Solid state auto switch (3-wire, 2-wire)

Note) Refer to pages 797 to 850 for further information on auto switches.

\* Use the gripper with dust cover when used in a place where there may be dust.

#### Model

Action			Bore	Gripping	force Note 1)	Opening/ Closing	Note 2)
		Model	size		Gripping force per finger Effective value (N)		Weight (g)
			(mm)	External	Internal	(mm)	
		MHZ2-6D	6	3.3	6.1	4	27
		MHZ2-10D(N)	10	11	17	4	55
Doub	lo.	MHZ2-16D(N)	16	34	45	6	115
actin		MHZ2-20D(N)	20	42	66	10	230
acun	g	MHZ2-25D(N)	25	65	104	14	420
		MHZ2-32D	32	158	193	22	715
		MHZ2-40D	40	254	318	30	1275
		MHZ2-6S	6	1.9		4	27
	open	MHZ2-10S(N)	10	7.1		4	55
		MHZ2-16S(N)	16	27		6	115
	ally	MHZ2-20S(N)	20	33	—	10	235
	Normally	MHZ2-25S(N)	25	45		14	425
	ž	MHZ2-32S	32	131		22	760
Single		MHZ2-40S	40	217		30	1370
acting		MHZ2-6C	6		3.7	4	27
	sed	MHZ2-10C(N)	10		13	4	55
Normally closed	clo	ອິ MHZ2-16C(N) 16	38	6	115		
	È	MHZ2-20C(N)	20	_	57	10	235
	ma	MHZ2-25C(N)	25		83	14	425
	MHZ2-32C	32		161	22	760	
		MHZ2-40C	40		267	30	1370

Note 2) Values excluding weight of auto switch.

## Option


#### Body Option/End Boss Type

-										
Symbol	Piping port		Type of piping port					Applicable model		
Symbol	location	MHZ2-6	MHZ2-10	MHZ2-16	MHZ2-20	MHZ2-25	MHZ2-32	MHZ2-40	Double acting	Single acting
Nil	Basic type	M3 :	x 0.5	M5 x 0.8			3		•	•
Е	Side ported	_	M3 x 0.5	I	M5 x 0.8 —			•		
W	Axial ported	_	With ø4 C	)ne-touch fi	tting for coa	ixial tubing	-	_	•	—
к	Axial ported	—	With ø4 One-touch fitting			-	-	—	•	
М	Axial ported	—		M5 x 0.8			-	-	—	

\* For detailed body option specifications, refer to option specifications on pages 424 and 425.

# MHZ2 Series

## **Clean Series: Air Gripper**



Applicable Auto Switches/Refer to pages 797 to 850 for further information on the auto switch.

	Oracial	El catalora l	In all a set a se	Marine a	1.	oad voltage		Auto swite	ch model	Lead	wire I	ength	(m) *							
Туре	Special function	entry	Indicator light	Wiring		3		Loau voltage		Load voltage		Electrical en	try direction	0.5	1	3	5	Pre-wired connector	Appli	ad
	Iuncion	entry	ligin	(Output)				Perpendicular	In-line	(Nil)	(M)	(L)	(Z)	CONNECTOR	10	au				
				3-wire (NPN)				M9NV	M9N	•	٠	٠	0	0						
				3-wire (INPIN)		5 V. 12 V		F8N	_	٠	—	٠	0	-	IC					
ج ح				Quuine (DND)		5 V, 12 V		M9PV	M9P	•	•	•	0	0	circuit					
switch	_			3-wire (PNP)			F8P	—	•	—	•	0	_							
				2-wire		12 V		M9BV	M9B	•	٠	•	0	0						
auto		Grommet	Yes	2-wire	24 V	12 V		F8B	_	•	-	•	0	_	_	Relay,				
state	Diagnosis	Giommet	les	3-wire (NPN)	24 V	5 V. 12 V	_	M9NWV	M9NW	•	٠	•	0	0	IC	PLC				
	(2-color			3-wire (PNP)		J V, 12 V		M9PWV	M9PW	•	٠	•	0	0	circuit					
Solid	indicator)			2-wire		12 V		M9BWV	M9BW	•	•	•	0	0	—					
S S	Water resistant			3-wire (NPN)		5 V, 12 V		M9NAV**	M9NA**	0	0	٠	0	0	IC					
	(2-color			3-wire (PNP)		J V, 12 V		M9PAV**	M9PA**	0	0	٠	0	0	circuit					
	indicator)			2-wire		12 V		M9BAV**	M9BA**	0	0	•	0	0	—					

\* \* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance.

\* Lead wire length symbols: 0.5 m ..... Nil (Example) M9NW

\* Solid state auto switches marked with O are produced upon receipt of order.

1 m······ M (Example) M9NWM

3 m ..... L (Example) M9NWL


5 m······ Z (Example) M9NWZ

Note 4) Two extension fitting assemblies (P331176A) are supplied with 11-MHZ2-10DE. Please use them if the fitting interferes with the auto switch.

#### Specifications

Fluid	Air	
Operating pressure	ø10: 0.2 to 0.7 MPa ø16 to ø25: 0.1 to 0.7 MPa	
Ambient and fluid temperature	-10 to 60°C	
Repeatability	±0.01 mm	
Max. operating frequency	180 c.p.m.	
Lubrication	Not required	
Action	Double acting	
Cleanliness class (ISO class)	Class 4	
Auto switch (Option)	Solid state auto switch (3-wire, 2-wire)	






#### Vacuum port


The concentrated vacuuming of internally generated particulates prevents them from spreading into the clean room.

For details, refer to "Pneumatic Clean Series (CAT. E02-23)" catalog.


#### Construction: MHZ2-6

#### Double acting/With fingers open





#### Double acting/With fingers closed



#### **Component Parts**


No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Piston	Stainless steel	
3	Lever	Stainless steel	Heat treated
4	Guide	Stainless steel	Heat treated
5	Finger	Stainless steel	Heat treated
6	Roller stopper	Stainless steel	
7	Lever shaft	Stainless steel	Nitriding
8	Magnet holder	Stainless steel	
9	Holder	Brass	Electroless nicked plated
10	Holder lock	Stainless steel	
11	Сар	Aluminum alloy	Clear anodized
12	Bumper	Urethane rubber	
13	Magnet	_	Nickel plated

#### **Replacement Parts**


Desci	ription	MHZ2-6	Main parts			
Finger assembly		Please contact SMC to replace the seal kit and finger assembly.				
	MHZ2-6D	MHZ-A0603	28910121315212223			
Piston assembly	MHZ2-6SD	WITZ-AU003	2030020302020			
	MHZ2-6C	MHZ-A0603C	28910121315221223			

Replacement part/Grease pack part no.: GR-S-010 (10 g)

#### Single acting/Normally open



## Single acting/Normally closed



# MHZ MHF MHL MHR MHR MHK MHK MHK MHY MHW -X MRHQ D-D


#### **Component Parts**

No.	Description	Material	Note
14	Steel balls	High carbon chrome bearing steel	
15	Needle roller	High carbon chrome bearing steel	
16	Type C retaining ring	Carbon steel	Phosphate coated
17	Exhaust plug	Brass	Electroless nickel plated
18	Exhaust filter	Polyvinyl formal	
19	N.O. spring	Stainless steel spring wire	
20	N.C. spring	Stainless steel spring wire	
21	Rod seal	NBR	
22	Piston seal	NBR	
23	Gasket	NBR	
24	Gasket	NBR	


# MHZ2 Series

#### Construction: MHZ2-10 to 25

#### Double acting/With fingers open




#### Double acting/With fingers closed




#### **Component Parts**

No.	Description	Material	Note	
1	Body	Aluminum alloy	Hard anodized	
2	Piston	ø10, ø16: Stainless steel ø20, ø25: Aluminum alloy	ø20, ø25: Hard anodized	
3	Lever	Stainless steel	Nitriding	
4	Guide	Stainless steel	Heat treated	
5	Finger	Stainless steel	Heat treated	
6	Roller stopper	Stainless steel		
7	Lever shaft	Stainless steel	Nitriding	
8	Seal support	Stainless steel		
9	Rod cover	Synthetic resin		
10	Сар	Synthetic resin	Single acting/Normally open only	
11	Bumper	Urethane rubber		

#### Single acting/Normally open



#### Single acting/Normally closed



#### **Component Parts**

No.	Description	Material	Note
12	Rubber magnet	Synthetic rubber	
13	Steel balls	High carbon chrome bearing steel	
14	Needle roller	High carbon chrome bearing steel	
15	Type C retaining ring	Carbon steel	Phosphate coated Single acting/Normally open only
16	Exhaust plug A	Brass	Electroless nickel plated
17	Exhaust filter A	Polyvinyl formal	
18	N.O. spring	Stainless steel spring wire	
19	N.C. spring	Stainless steel spring wire	
20	Rod seal	NBR	
21	Piston seal	NBR	
22	Gasket	NBR	

#### **Replacement Parts**

Desc	cription	MHZ2-10	MHZ2-16	MHZ2-20	MHZ2-25	Main parts
Seal kit	MHZ2-DDD MHZ2-DDCD	MHZ10-PS	MHZ16-PS	MHZ20-PS	MHZ25-PS	202122
	MHZ2-DDSD	MHZ10S-PS	MHZ16S-PS	MHZ20S-PS	MHZ25S-PS	1
	MHZ2-□□□(N)	MHZ-AA1002(N)	MHZ-AA1602(N)	MHZ-AA2002(N)	MHZ-AA2502(N)	
Firmer constants	MHZ2-□□□(N)1	MHZ-AA1002(N)-1	MHZ-AA1602(N)-1	MHZ-AA2002(N)-1	MHZ-AA2502(N)-1	45613
Finger assembly	MHZ2-□□□(N)2	MHZ-AA1002(N)-2	MHZ-AA1602(N)-2	MHZ-AA2002(N)-2	MHZ-AA2502(N)-2	Mounting screw
	MHZ2-DDD3	MHZ-AA1002-3	MHZ-AA1602-3	MHZ-AA2002-3	MHZ-AA2502-3	1
	MHZ2-DDD		MHZ-AA1603	MHZ-AA2003	MHZ-AA2503	
Piston assembly	MHZ2-DDSD	MHZ-AA1003				2111214
	MHZ2-DDCD					
	MHZ2-DDDW	MHZ-A1007	MHZ-A1607	MHZ-A2007	MHZ-A2507	Main hade of adapte
End boss assembly	MHZ2-DDDDK	MHZ-A1008	MHZ-A1608	MHZ-A2008	MHZ-A2508	Main body of adapto
Lifu boss assembly	MHZ2-DDDDM	MHZ-A1009	MHZ-A1609	MHZ-A2009	MHZ-A2509	Mounting screw for adapto
	MHZ2-DDDDE	MHZ-A1010	MHZ-A1610	MHZ-A2010	MHZ-A2510	Seal
Lever assembly		MHZ-AA1004	MHZ-AA1604	MHZ-AA2004	MHZ-AA2504	3
* Finger option	TH			Replacement part/Gre	ease pack part no.: GR	-S-010 (10 g)

1 = Side tapped, 2 = Through-hole, 3 = Flat type fingers

\* End boss type


W = One-touch-fitting for coaxial tubing, K = With One-touch fitting, M = With M5 port, E = Side ported

\* The end boss assembly other than type E should be mounted on the special body.


414



#### Construction: MHZ2-32 to 40



#### Double acting/With fingers closed



#### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Piston	Aluminum alloy	Hard anodized
3	Lever	Stainless steel	Heat treated
4	Guide	Stainless steel	Heat treated
5	Finger	Stainless steel	Heat treated
6	Roller stopper	Stainless steel	
7	Lever shaft	Stainless steel	Nitriding
8	Сар	Aluminum alloy	Clear anodized
9	Bumper	Urethane rubber	
10	Rubber magnet	Synthetic rubber	
11	Steel balls	High carbon chrome bearing steel	


#### **Replacement Parts**

Description		MHZ2-32	MHZ2-40	Main parts	
Seal kit		MHZ32-PS	MHZ40-PS	192021	
	MHZ2-□□□(N)	MHZ-A3202	MHZ-A4002		
Finger assembly	MHZ2-□□□(N)1	MHZ-A3202-1	MHZ-A4002-1	456113	
ringer assembly	MHZ2-□□□(N)2	MHZ-A3202-2 MHZ-A4002-2		Mounting screw	
	MHZ2-003	MHZ-A3202-3	MHZ-A4002-3		
	MHZ2-DDD	MHZ-A3203	MHZ-A4003		
Piston assembly	MHZ2-DDSD	MHZ-A3203S	MHZ-A4003S	291012	
	MHZ2-DDCD	WITZ-A32035	MINZ-A40033		
Lever assembly		MHZ-A3204	MHZ-A4004	3	


\* Finger option

1 = Side tapped, 2 = Through-hole, 3 = Flat type fingers

#### Single acting/Normally open



Single acting/Normally closed



# Component Parts No. Description

No.	Description	Material	Note
12	Needle roller	High carbon chrome bearing steel	
13	Parallel pin	Stainless steel	
14	Type C retaining ring	Carbon steel	Phosphate coated
15	Exhaust plug A	Brass	Electroless nickel plated
16	Exhaust filter A	Polyvinyl formal	
17	N.O. spring	Stainless steel spring wire	
18	N.C. spring	Stainless steel spring wire	
19	Rod seal	NBR	
20	Piston seal	NBR	
21	Gasket	NBR	

MHR MHK MHS MHC MHT MHY -X MRHQ MRHQ D-

MHZ Mhf Mhl

Replacement part/Grease pack part no.: GR-S-010 (10 g)


# **MHZ2** Series

#### Dimensions

#### MHZ2-6 Double acting/Single acting **Basic type**

Use the MHZJ2 series with a dust cover when used in a place where there may be dust.






5.5


17

\* For single action, the port on one side is a breathing hole.

2.5 5







# MHZ2-10□ Double acting/Single acting


Use the MHZJ2 series with a dust cover when used in a place where there may be dust.

## MHZ2 Series

#### Dimensions

## MHZ2-16 Double acting/Single acting Basic type


Use the MHZJ2 series with a dust cover when used in a place where there may be dust.



**SMC** 

## MHZ2-20 Double acting/Single acting Basic type

Use the MHZJ2 series with a dust cover when used in a place where there may be dust.




## MHZ2 Series

#### Dimensions


## MHZ2-25 Double acting/Single acting Basic type

Use the MHZJ2 series with a dust cover when used in a place where there may be dust.



**SMC** 

## Parallel Type Air Gripper/Standard Type MHZ2 Series




Note) Through-hole mounting is not possible when using the auto switch at the square groove.

-X□

## MHZ2 Series

#### Dimensions

### MHZ2-40 Double acting/Single acting




Note) Through-hole mounting is not possible when using the auto switch at the square groove.

3.7

**SMC** 

# Standard Type/MHZ2 Series **Finger Option**


### Side Tapped Mounting [1/N1]




				(mm)
Model	Α	В	С	MM
MHZ2-6 1	2.5	5	2	M2 x 0.4
MHZ2-10	3	5.7	2	M2.5 x 0.45
MHZ2-16	4	7	2.5	M3 x 0.5
MHZ2-20	5	9	4	M4 x 0.7
MHZ2-25	6	12	5	M5 x 0.8
MHZ2-32 1	7	14	6	M6 x 1
MHZ2-40 1	9	17	7	M8 x 1.25

\* Specifications and dimensions other than the above are the same as the basic type (including narrow type).


### Flat Type Fingers [3]



### Through-holes in Opening/ Closing Direction [2/N2]




4 x øH through



			(mm)
Model	Α	В	н
MHZ2-622	2.5	5	2.4
MHZ2-10	3	5.7	2.9
MHZ2-16	4	7	3.4
MHZ2-20	5	9	4.5
MHZ2-25	6	12	5.5
MHZ2-32 2	7	14	6.6
MHZ2-40 2	9	17	9

¢

\* Specifications and dimensions other than the above are the same as the basic type (including narrow type).



0 -0

							2						Weight	
Model	A	В	C	D	F	Open	Closed	J	ĸ	ММ	L	W	U 0	<b>D</b> -□
MHZ2-6 3 (1)	2	3.5	7.2	7.5	_	5 <sup>+1.2</sup> -0.8	1 <sup>+0.2</sup>	—	—	M2 x 0.4	3	4_0.05	26	
MHZ2-10_3_ (2)(3)	2.45	6	5.2	10.9	2	5.4 +2.2	1.4_0.2	4.45	2H9 <sup>+0.025</sup>	M2.5 x 0.45	5	5 <sup>0</sup> <sub>-0.05</sub>	55	
MHZ2-16 3 (2)(3)	3.05	8	8.3	14.1	2.5	7.4 +2.2	1.4_0.2	5.8	2.5H9 <sup>+0.025</sup>	M3 x 0.5	6	8_0.05	115	
MHZ2-203	3.95	10	10.5	17.9	3	11.6 +2.3	1.6_0_2	7.45	3H9 <sup>+0.025</sup>	M4 x 0.7	8	10_0.05	225 (230)	
MHZ2-25_3_ (2)(3)	4.9	12	13.1	21.8	4	16 +2.5	2 _0.2	8.9	4H9 <sup>+0.030</sup>	M5 x 0.8	10	12_0_05	410 (415)	
MHZ2-32[]3[]	7.3	20	18	34.6	5	25 +2.7	3 <sup>0</sup> <sub>-0.2</sub>	14.8	5H9 <sup>+0.030</sup>	M6 x 1	12	15 <sub>-0.05</sub>	740 (785)	
MHZ2-40_3_	8.7	24	22	41.4	6	33 <sup>+2.9</sup>	3 <sup>0</sup> <sub>-0.2</sub>	17.7	6H9 <sup>+0.030</sup>	M8 x 1.25	16	18 <sup>0</sup> -0.05	1335 (1430)	

C

Note 1) To mount attachments, use JISB1101 type M2 round head screws. Be careful not to use commercially available M2 hexagon socket head cap bolt as its top diameter is large. Note 2) Specifications and dimensions other than the above are the same as the basic type (including narrow type).

Note 3) The overall length is the same as the MHQ(G) flat finger type.

Note 4) The values inside ( ) are for the single acting type.

**SMC** 

423

МНК MHS MHC МНТ MHY MHW -X□ MRHQ (mm) MA

MHZ MHF

MHL


MHR

# Standard Type/*MHZ2* Series Body Option: End Boss Type

### **Applicable Model**

			Type of p	iping port	Applicable model				
Symbol	Piping port location	MHZ2-10	MHZ2-16 MHZ2-20		MHZ2-25	Double acting	Single	acting	
		WH22-10	101122-10	WIT122-20	WH22-25	Double acting	Normally open	Normally closed	
E	Side ported	M3 x 0.5		M5 x 0.8		•	•	•	
w		With ø	4 One-touch fitt	ing for coaxial t	ubing	•	—	_	
к	Axial ported		With ø4 One	-touch fitting		—	•	•	
М			M5 >	0.8		_	•	•	

### Side Ported [E]




					(mm)
Model	Α	в	D1	D2	Е
MHZ2-10□□E	15	7	12f8 -0.016 -0.043	11	52.8
MHZ2-16□□E	20	10	16f8 -0.016 -0.043	15	58.7
MHZ2-20□□E	22	12	20f8 -0.020 -0.053	19	70.5
MHZ2-25	25	15	25f8 -0.020 -0.053	24	82.9

Other dimensions and specifications correspond to the standard type.

\* Refer to the dimension table.

\* When auto switches are used at the square groove on the side, side mounting with through-holes is not possible.

## Axial Ported (with One-touch fitting for coaxial tubing) [W]




\* Refer to the dimension table.

\* When auto switches are used at the square groove on the side, side mounting with through-holes is not possible.

#### Changing from Coaxial to Single Tubing

Changing to single tubing is possible by using a branch "Y" or branch tee fitting. In this case particularly, single tube fittings and tube for  $\sigma$ 3.2 will be necessary.



								(mm)
Model	Α	в	D1	D2	Е	F	G	н
MHZ2-10DDW	15	7	12f8 -0.016 -0.043	11	52.8	18	28.3	5.5
MHZ2-16DDW	20	10	$16f8 \ _{-0.043}^{-0.016}$	15	58.7	16.2	27.7	6.5
MHZ2-20D□W	22	12	20f8 -0.020 -0.053	19	70.5	18.2	31.2	7.5
MHZ2-25D UW	25	15	25f8 -0.020 -0.053	24	82.9	19	31.8	10

Other dimensions and specifications correspond to the standard type.

#### Applicable Coaxial Tubing


Reference symbol

I (Internal nase


	Applicable 00	axiai Tubilig
	Model Specifications	TW04B-20
	Outside diameter	4 mm
	Max. operating pressure	0.6 MPa
	Min. bending radius	10 mm
aqe)	Operating temperature	-20 to 60°C
agoj	Material	Nvlon 12

#### Branch Tee, Different Diameter Tee, Branch "Y", Male Run Tee

Please contact your SMC sales representative for details of the coaxial fittings and tubing.



**SMC** 



### Axial Ported (with One-touch fitting) [K]

\* Refer to the dimension table.

\* When auto switches are used at the square groove on the side, side mounting with through-holes is not possible.

Note 1) Normally open type plug position.

Note 2) Normally closed type plug position.

The plug is mounted on only one side for the single acting type.

								(mm)
Model	Α	в	D1	D2	Е	F	G	н
MHZ2-10 <sup>S</sup> CK	15	7	$12f8 \begin{array}{c} ^{-0.016}_{-0.043} \end{array}$	11	52.8	18	28.3	5.5
MHZ2-16 <sup>S</sup> CK	20	10	$16f8 \ \substack{-0.016\\-0.043}$	15	58.7	16.2	27.7	6.5
МНZ2-20 <sup>S</sup> □К	22	12	20f8 -0.020 -0.053	19	70.5	18.2	31.2	7.5
MHZ2-25 <sup>S</sup> CK	25	15	25f8 -0.020 -0.053	24	82.9	19	31.8	10

Other dimensions and specifications correspond to the standard type.

#### Applicable Tubing

Description/Model	Nylon tubing	Soft nylon tubing	Polyurethane tubing	Polyurethane coil tubing
Specifications	T0425	TS0425	TU0425	TCU0425B-1
Outside diameter (mm)	4	4	4	4
Max. operating pressure (MPa)	1.0	0.8	0.5	0.5
Min. bending radius (mm)	13	12	10	_
Operating temperature (°C)	-20 to 60	-20 to 60	-20 to 60	-20 to 60
Material	Nylon 12	Nylon 12	Polyurethane	Polyurethane

Refer to "Best Pneumatics No. 7" regarding One-touch fittings and tubing.

#### Auto switch mounting groove (4 locations) M5 x 0.8 Plug (Except ø10) Piping port ø10 : M-3F End boss assembly ø16 to 25: M-5F GՒ ã Φ ф 50 Φ F Note 2) в 5 F Auto switch mounting groove (Both sides)

								(mm)
Model	Α	в	D1	D2	Е	F	G	н
MHZ2-10 <sup>S</sup> CM	15	7	12f8 -0.016 -0.043	11	52.8	18	28.3	5.5
MHZ2-16 <sup>S</sup> 🗆 M	20	10	16f8 -0.016 -0.043	15	58.7	16.2	27.7	6.5
MHZ2-20 <sup>S</sup> CM	22	12	20f8 -0.020 -0.053	19	70.5	18.2	31.2	7.5
МНZ2-25 <sup>S</sup> □М	25	15	25f8 -0.020 -0.053	24	82.9	19	31.8	10

Other dimensions and specifications correspond to the standard type.

\* Refer to the dimension table.

\* When auto switches are used at the square groove on the side, side mounting with through-holes is not possible.

Note 1) Normally open type plug position.

Note 2) Normally closed type plug position.

The plug is mounted on only one side for the single acting type.

### Weight

				(g)	-X□
Model		End boss ty	pe (Symbol)		MDUO
Woder	E	W	к	М	MRHQ
MHZ2-10	65	64	66	65	MA
MHZ2-16	148	147	148	147	
MHZ2-20	272	277	277	277	D-□
MHZ2-25	485	495	496	494	

MHZ

MHF

MHL

MHR

МНК

MHS

MHC

МНТ

MHY Mhw

## Axial Ported (with M5 Port) [M]

# Parallel Type Air Gripper/Long Stroke Type MHZL2 Series Ø10, Ø16, Ø20, Ø25

How to Order MHZL2-16 D M9BW Number of fingers Made to Order Refer to page 427 for details. 2 2 fingers Number of auto switches Bore size 10 10 mm Nil 2 pcs. Action Auto switch 16 16 mm s 1 pc. D Double acting Nil Without auto switch (Built-in magnet) 20 20 mm n n pc. S Single acting (Normally open) 25 25 mm \* For the applicable auto switch model, C Single acting (Normally closed) refer to the table below. Finger option Body option Nil: Basic type E: End boss type W: End boss type Nil: Basic type 1: Side tapped Side ported Axial ported with ø4 mounting (Double acting/ One-touch fitting for coaxial tubing Single acting) (Double acting) Port Port Port 2: Through-holes in 3: Flat type fingers opening/closing direction Port K: End boss type M: End boss type Axial ported with Axial ported ø4 One-touch with M5 port fitting (Single acting)

#### Applicable Auto Switches/Refer to pages 797 to 850 for further information on the auto switch

								Auto swit	ch model	Lead	wire I	ength	(m) *	Арр	licab	le mo	odel					
Туре	Special function	Electrical entry	Indicator light	Wiring (Output)		Loau voltage		Load voltage		Electrical en	Electrical entry direction		1	3	5			- 00		Pre-wired connector	Applicable load	
	lanoton	entry	iigiii	(Output)		DC	AC	Perpendicular	In-line	(Nil)	(M)	(L)	(Z)	ø10	Ø16	Ø20	Ø25			uu		
								M9NV	M9N	٠	•	٠	0	٠	٠	٠	•	0				
				3-wire (NPN)		5V. 12 V		F8N	_	٠	-	٠	0	—	•	•	•	-				
c	_					5V, 12 V		M9PV	M9P	٠	•	٠	0	٠	٠	٠	٠	0	circuit			
switch				3-wire (PNP)				F8P	—	•	-	٠	0	—	٠	•	•	-	]			
				2-wire		12 V		M9BV	M9B	•	•	•	0	•	٠	٠	٠	0				
auto		Grommet	Yes	2-wire	24 V	12 V		F8B	—	•	-	٠	0	—	٠	٠	•	—		Relay,		
state	Diagnosis	Citorinine	163	3-wire (NPN)	24 V	5 V. 12 V	_	M9NWV	M9NW	•	•	٠	0	•	٠	•	•	0	IC	PLC		
	(2-color			3-wire (PNP)		5 V, 12 V		M9PWV	M9PW	•	•	•	0	•	٠	•	٠	0	circuit			
Solid	indicator)			2-wire		12 V		M9BWV	M9BW	٠	•	٠	0	٠	٠	٠	٠	0	-			
0)	Water resistant			3-wire (NPN)		5 V. 12 V		M9NAV**	M9NA**	0	0	٠	0	•	٠	•	•	0	IC			
	(2-color			3-wire (PNP)		5 V, 12 V		M9PAV**	M9PA**	0	0	•	0	•	٠	•	•	0	circuit			
	indicator)			2-wire		12 V		M9BAV**	M9BA**	0	0	٠	0	٠	٠	٠	•	0	-	1		

(Single acting)

\*\* Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance.

\* Lead wire length symbols: 0.5 m ----- Nil (Example) M9NW \* Solid state auto switches marked with O are produced upon receipt of order.

- 1 m ..... M (Example) M9NWM
- 3 m ..... L (Example) M9NWL
- 5 m······ Z (Example) M9NWZ

Note 1) When using the 2-color indicator type, please make the setting so that the indicator is lit in red to ensure the detection at the proper position of the air gripper. Note 2) Through-hole mounting is not possible when using the auto switch at the square groove on the side.

Note 3) When the product is ordered with auto switch, only MHZL2-10 is shipped with the auto switch mounting brackets. When the auto switch is used at the square groove on the side with MHZL2-16 to 25, mounting brackets (BMG2-012) are required. Order them separately. Refer to page 457 for the auto switch mounting brackets.

426





#### Symbol

Double acting: Internal grip



Double acting: External grip



Single acting/ Normally closed: Internal grip



Single acting/ Normally open: External grip



## Refer to pages 454 to 458 for the specifications with auto switch.

- Auto switch installation examples and mounting positions
- Auto switch hysteresis
- Auto switch mounting
- · Protrusion of auto switch from edge of body



Made to Order Individual Specifications (Refer to pages 436 to 439 for details.)

Symbol	
-X6110□	With dust cover

### Made to Order

Click her	e for details
Symbol	Specifications/Description
-X4	Heat resistance (100°C)
-X5	Fluororubber seal
-X7	Closing direction spring assist
-X12	Opening direction spring assist
-X50	Without magnet
-X53	EPDM seal/Fluorine grease
-X56	Axial ported type
-X63	Fluorine grease
-X79	Grease for food processing machines, Fluorine grease
-X79A	Grease for food processing machines
-X81A	Anti-corrosive treatment of finger
-X81B	Anti-corrosive treatment of finger and guide

### Specifications

	Fluid		Air
	·		ø10: 0.2 to 0.7 MPa
Operating			ø16 to ø25: 0.1 to 0.7 MPa
pressure			ø10: 0.35 to 0.7 MPa
			ø16 to ø25: 0.25 to 0.7 MPa
Ambient a	Ambient and fluid temperature		-10 to 60°C
Repeatab	ility		±0.01 mm
Max. oper	ating fr	equency	120 c.p.m.
Lubrication			Not required
Action			Double acting/Single acting
Auto swit	Auto switch (Option) Note) Solid state auto		Solid state auto switch (3-wire, 2-wire)

Note) Refer to pages 797 to 850 for further information on auto switches.

### Model

Action			_	Gripping	Gripping force Note 1)		
		Model	Bore size		Gripping force per finger Effective value (N)		Weight (g)
			(mm)	External	Internal	(mm)	
		MHZL2-10D	10	11	17	8	60
Doubl	e	MHZL2-16D	16	34	45	12	135
actin	g	MHZL2-20D	20	42	66	18	270
	-	MHZL2-25D	25	65	104	22	470
	en	MHZL2-10S	10	7.1		8	70
	ly op	MHZL2-16S	16	27		12	145
	Normally open	MHZL2-20S	20	33	_	18	290
Single		MHZL2-25S	25	50		22	515
acting	closed	MHZL2-10C	10		13	8	70
	Clo	MHZL2-16C	16		38	12	145
	Vormally	MHZL2-20C	20	_	57	18	290
	Non	MHZL2-25C	25		85	22	515

Note 1) Values based on pressure of 0.5 MPa, gripping point L = 20 mm, at center of stroke. Note 2) Values excluding weight of auto switch.

### Option

#### Body Option/End Boss Type

		-	•				
	Piping port		Type of piping port			Applicat	ole model
Symbol	location	MHZL2-10	MHZL2-10 MHZL2-16 MHZL2-20 MHZL2-25 Double				Single acting
Nil	Basic type	M3 x 0.5	M3 x 0.5 M5 x 0.8				
Е	Side ported	M3 x 0.5 M5 x 0.8			•	•	
w	Axial ported	With ø4 One-touch fitting for coaxial tubing			•	—	
к	Axial ported		With ø4 One-touch fitting			—	
М	Axial ported	M5 x 0.8 —					
· · · · · · · · · · · · · · · · · · ·	•						

\* For detailed body option specifications, refer to option specifications on pages 434 and 435.

MHZ



When operating an actuator with a small diameter and a short stroke at a high frequency, the dew condensation (water droplet) may occur inside the piping depending on the conditions.


Simply connecting the moisture control tube to the actuator will prevent dew condensation from occurring. For details, refer to the IDK series in the Best Pneumatics No. 6.

## **SMC**


## MHZL2 Series

### Construction: MHZL2-10 to 25

#### Double acting/With fingers open



#### Double acting/With fingers closed



#### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Piston	ø10, ø16: Stainless steel ø20, ø25: Aluminum alloy	ø20, ø25: Hard anodized
3	Lever	Stainless steel	Nitriding
4	Guide	Stainless steel	Heat treated
5	Finger	Stainless steel	Heat treated
6	Roller stopper	Stainless steel	
7	Lever shaft	Stainless steel	Nitriding
8	Сар	Aluminum alloy	Clear anodized
9	Bumper	Urethane rubber	

#### **Replacement Parts**

#### Description MHZL2-10 MHZL2-16 MHZL2-20 MHZL2-25 Main parts MHZL10-PS MHZL16-PS MHZL20-PS MHZL25-PS 171819 Seal kit MHZL2-DDD MHZL-AA1002 MHZL-AA1602 MHZL-AA2002 MHZL-AA2502 MHZL2-DDD1 4561 MHZL-AA1002-1 MHZL-AA1602-1 MHZL-AA2002-1 MHZL-AA2502-1 Finger assembly MHZL2-DDD2 MHZL-AA1002-2 MHZL-AA1602-2 MHZL-AA2002-2 MHZL-AA2502-2 Mounting screw MHZL2-DDD3 MHZL-AA1002-3 MHZL-AA1602-3 MHZL-AA2002-3 MHZL-AA2502-3 MHZL2-DDD MHZI -A1603 MHZI - A2003 MHZI - A2503 MHZI -A1003 Piston assembly 291012 MHZL2-DDSD MHZL-A1003C MHZL-A1603C MHZL-A2003C MHZL-A2503C MHZL2-DDCD MHZ-A1007 MHZ-A1607 MHZ-A2007 MHZ-A2507 MHZL2-DDDW Main body of adaptor MHZL2-DDDDK MHZ-A1008 MHZ-A1608 MHZ-A2008 MHZ-A2508 End boss assembly Mounting screw for adaptor MHZ-A1009 MHZ-A1609 MHZ-A2009 MHZ-A2509 MHZL2-DDDDM Seal kit MHZL2-DDDDE MHZ-A1010 MHZ-A1610 MHZ-A2010 MHZ-A2510

Lever assembly \* Finger option

1 = Side tapped, 2 = Through-hole, 3 = Flat type fingers

\* End boss type

W = One-touch-fitting for coaxial tubing, K = With One-touch fitting, M = With M5 port, E = Side ported

MHZL-A1004

\* The end boss assembly other than type E should be mounted on the special body


A 428

## **SMC**


MHZL-A1604

MHZL-A2004

#### Single acting/Normally open



#### Single acting/Normally closed



#### **Component Parts**


No.	Description	Material	Note
10	Rubber magnet	Synthetic rubber	
11	Steel balls	High carbon chrome bearing steel	
12	Needle roller	High carbon chrome bearing steel	
13	Type C retaining ring	Carbon steel	Phosphate coated
14	Exhaust plug A	Brass	Electroless nickel plated
15	Exhaust filter A	Polyvinyl formal	
16	Spring	Stainless steel spring wire	
17	Rod seal	NBR	
18	Piston seal	NBR	
19	Gasket	NBR	

MHZL-A2504 Replacement part/Grease pack part no.: GR-S-010 (10 g)

37

#### Dimensions

#### MHZL2-10 Double acting/Single acting Basic type



Note) Through-hole mounting is not possible when using the auto switch at the square groove.

6.2

4.0

€

MHZ

MHF

MHL

MHR

MHK MHS

MHC

МНТ

MHY

MHW

-X□


MRHQ

MA D-

## MHZL2 Series

#### Dimensions


### MHZL2-16 Double acting/Single acting



Note) Through-hole mounting is not possible when using the auto switch at the square groove.

**SMC** 

#### MHZL2-20 Double acting/Single acting Basic type



Note) Through-hole mounting is not possible when using the auto switch at the square groove.

mounting groove

431

2.1

MHZ

MHF

MHL

MHR

МНК

MHS Mhc

МНТ

MHY

MHW

-X□

MRHQ


MA

D-🗆


## MHZL2 Series


#### Dimensions

## MHZL2-25 Double acting/Single acting Basic type




The values inside ( ) are dimensions for the single acting type.





\* For single action, the port on one side is a breathing hole.

#### Auto Switch Mounting Groove Dimensions




Note) Through-hole mounting is not possible when using the auto switch at the square groove.

**SMC** 

# Long Stroke Type/*MHZL2* Series Finger Option


### Side Tapped Mounting [1]




				(mm)
Model	Α	В	С	MM
MHZL2-10□1□	3	5.7	2	M2.5 x 0.45
MHZL2-16□1□	4	7	2.5	M3 x 0.5
MHZL2-20□1□	5	9	4	M4 x 0.7
MHZL2-25□1□	6	12	5	M5 x 0.8

\* Specifications and dimensions other than the above are the same as the basic type.

### Flat Type Fingers [3]






Model

MHZL2-10
2

MHZL2-16□2□

MHZL2-20 2


MHZL2-25 2



 Specifications and dimensions other than the above are the same as the basic type.

Through-holes in Opening/ Closing Direction [2]

## 



		_

MHC Mht Mhy

MHZ

MHF

MHL

МНК

MHS

- MHW
- -X□
- MRHQ
- MA

Weight (g) G Model Α в С D F J к MM L w Double Single acting Open Closed MHZL2-10 3 2.45 7 5.2 11.9 2 9.4+2.2 1.4\_0 2 4.95 2H9+0.025 M2.5 x 0.45 5 5 % 70 60 .05 13.4+2.2 1.4\_0 3.3 9 8.3 15.7 2.5 6.55 2.5H9+0.025 M3 x 0.5 6 135 145 MHZL2-16□3□ 8\_ 0.05 19.6<sup>+2.4</sup> 1.6<sup>0</sup><sub>-0.2</sub> MHZL2-20 3 3.95 12 10.5 19.9 3 8.45 3H9+0.025 M4 x 0.7 8 10\_0 270 290 .05 24 +2.6 4H9<sup>+0.030</sup> 2 \_0.2 MHZL2-25 3 4.9 14 13.1 23.8 4 9.9 M5 x 0.8 10 12\_0 460 505

\* Specifications and dimensions other than the above are the same as the basic type.


(mm)

# Long Stroke Type/*MHZL2 Series* Body Option: End Boss Type

### **Applicable Model**

			Type of piping port				Applicable mode	el		
Symbol	Piping port location	MHZL2-10	MHZL2-16	MHZL2-20	MHZL2-25	Double acting	Single	acting		
		WHZLZ-10	WHZLZ-10	WHZLZ-20	MHZEZ-20 MHZEZ-25		MINZLZ-20 WINZLZ-25	Double acting	Normally open	Normally closed
E	Side ported	M3 x 0.5	M3 x 0.5 M5 x 0.8			•	•	•		
w		With a	With ø4 One-touch fitting for coaxial tubing			•	—	—		
К	Axial ported		With ø4 One-touch fitting			—	•	•		
М			M5 x 0.8			—	•	•		

### Side Ported [E]



						(mm)
Model	Α	в	D1	D2	E1	E2
MHZL2-10□□E	15	7	12f8 -0.016 -0.043	11	52.8	62.8
MHZL2-16	20	10	16f8 -0.016 -0.043	15	61.4	66.4
MHZL2-20	22	12	20f8 -0.020 -0.053	19	75.7	81.7
MHZL2-25	25	15	25f8 -0.020 -0.053	24	86.2	96.2


Other dimensions and specifications correspond to the standard type.

\* Refer to the dimension table.

\* When auto switches are used at the square groove on the side, side mounting with through-holes is not possible.

## Axial Ported (with One-touch fitting for coaxial tubing) [W]

Re



\* Refer to the dimension table.


\* When auto switches are used at the square groove on the side, side mounting with through-holes is not possible.

	ference symbol
O (External passage)	O (External passage)

(Internal passage)

#### Changing from Coaxial to Single Tubing

Changing to single tubing is possible by using a branch "Y" or branch tee fitting. In this case particularly, single tube fittings and tubing for  $\emptyset$ 3.2 will be necessary.



					(11111)
Model	Α	в	D1	D2	E1
MHZL2-10DDW	15	7	12f8 -0.016 -0.043	11	52.8
MHZL2-16DDW	20	10	16f8 -0.016 -0.043	15	61.4
MHZL2-20D W	22	12	20f8 -0.020 -0.053	19	75.7
MHZL2-25D W	25	15	25f8 -0.020 -0.053	24	86.2
		- 41		d a such de su	

Other dimensions and specifications correspond to the standard type.

#### Applicable Coaxial Tubing Type W


Model Specifications	TW04B-20
Outside diameter	4 mm
Max. operating pressure	0.6 MPa
Min. bending radius	10 mm
Operating temperature	-20 to 60°C
Material	Nylon 12

ıy	Type v	v		
		F	G	н
	ø10	17	30	5.5
	ø16	16.7	33.7	6.5
	ø20	18.2	38.2	7.5
	ø25	18.3	41.3	10
•				


(mm)

#### Branch tee, Different diameter tee, Branch "Y", Male run tee

Please contact your SMC sales representative for details of the coaxial fittings and tubing.



### Axial Ported (with One-touch fitting) [K]



\* Refer to the dimension table.

\* When auto switches are used at the square groove on the side, side mounting with through-holes is not possible.

Note 1) Normally open type plug position.

Note 2) Normally closed type plug position.

The plug is mounted on only one side for the single acting type.

					(mm)
Model	Α	в	D1	D2	E2
MHZL2-10 <sup>S</sup> □K	15	7	12f8 -0.016 -0.043	11	62.8
MHZL2-16 <sup>S</sup> ⊡K	20	10	16f8 -0.016 -0.043	15	66.4
MHZL2-20 <sup>S</sup> □K	22	12	20f8 -0.020 -0.053	19	81.7
MHZL2-25 <sup>S</sup> □K	25	15	25f8 -0.020 -0.053	24	96.2

Other dimensions and specifications correspond to the standard type.

#### Applicable Tubing

Description/	Nylon	Soft nylon	Polyurethane	Polyurethane
Model	tubing	tubing	tubing	coil tubing
Specifications	T0425	TS0425	TU0425	TCU0425B-1
Outside diameter (mm)	4	4	4	4
Max. operating pressure (MPa)	1.0	0.8	0.5	0.5
Min. bending radius (mm)	13	12	10	—
Operating temperature (°C)	-20 to 60	-20 to 60	-20 to 60	-20 to 60
Material	Nvlon 12	Nvlon 12	Polyurethane	Polvurethane

Refer to "Pneumatic Piping Equipment (CAT. E50)" regarding One-touch fittings and tubing

#### Type K

.,	-		
	F	G	Н
ø <b>10</b>	17	40	5.5
ø16	16.7	38.7	6.5
ø <b>20</b>	18.2	44.2	7.5
ø <b>25</b>	18.3	51.3	10

## MHF MHL MHR MHK MHS MHC МНТ MHY MHW

MHZ

(mm)

66.4

96.2

D2 E2

11 62.8

15

19 81.7

> -X□ MRHQ

MA

D-🗆

### Weight

					(g)					
	End boss type (Symbol)									
Model	E	E		V						
	Double acting	Single acting	w	ĸ	м					
MHZL2-10-	70	80	70	80	80					
MHZL2-16-	170	180	170	180	180					
MHZL2-20-	310	330	310	330	330					
MHZL2-25-	535	580	535	580	580					

#### Model Α в D1 7 12f8 -0.016 MHZL2-10 C DM 15 16f8 -0.016 MHZL2-16 C DM 20 10 20f8 -0.020 MHZL2-20 C 22 12


25f8 -0.020 MHZL2-25 C DM 25 15 24 Other dimensions and specifications correspond to the standard type.

#### Type M

	F	G	н
ø <b>10</b>	17	40	5.5
ø <b>16</b>	16.7	38.7	6.5
ø <b>20</b>	18.2	44.2	7.5
ø <b>25</b>	18.3	51.3	10

435

## Axial Ported (with M5 port) [M]



\* Refer to the dimension table.

\* When auto switches are used at the square groove on the side, side mounting with through-holes is not possible.

Note 1) Normally open type plug position.

Note 2) Normally closed type plug position


The plug is mounted on only one side for the single acting type

Courtesy of Steven Engineering, Inc - (800) 258-9200 - sales@steveneng.com - www.stevenengineering.com

# **MHZL2** Series Made to Order Individual Specifications



Please contact SMC for detailed dimensions, specifications and lead times.



#### Specifications

Model	Basic type	Heat Fluororubl resistance seal					
Ambient and fluid temperature	-10 to 60°C -10 to 100°C -10 to 60°						
Specifications other than the above	Same as the standard type						

#### Model

			Gripping f			
Action	Model	Bore size (mm)		ce per finger value (N)	Closing stroke (Both sides)	Note 2) Weight (g)
		l` ´	External	Internal	(mm)	
	MHZL2-10D-X6110	10	11	17	8	85
Double acting	MHZL2-16D-X6110	16	34	45	12	150
aoung	MHZL2-20D-X6110	20	42	66	18	385

Note 1) Values based on pressure of 0.5 MPa, gripping point L = 20 mm, at

center of stroke. Note 2) Values excluding weight of auto switch.

## A Precautions

#### For fluororubber seal

Be aware that smoking cigarettes after your hands have come into contact with the grease used for this air gripper can create a gas that is hazardous to humans.

For heat resistance

#### 🗥 Caution

🕂 Warning

- Note 1) Magnet is built-in, but when using an auto switch, the acceptable temperature range becomes -10 to 60°C.
- Note 2) For the dust cover option part number, only fluororubber (F) or silicone rubber (S) can be selected.
- Note 3) For lubrication, specialized grease GR-F is recommended.

▲ Caution


- Note 1) Consult with SMC, since the type of chemical and the operating temperature may not allow the use of this product. Note 2) Since the standard-type magnet is built-in, consult with SMC
- for the product's adaptability to the operating environment. Note 3) The dust cover material is also fluororubber. Thus, enter (F)
  - for the fluororubber dust cover in the part number.

### **⊘**SMC

## Made to Order Individual Specifications MHZL2 Series

Dimensions

### MHZL2-10D -X6110 Basic type/Double acting




\* The dimensions of the heat resistance or fluororubber seal types are the same as those shown above.

MHF MHL MHR МНК MHS MHC MHT MHY MHW -X□ MRHQ MA D-🗆

MHZ

## MHZL2 Series


#### Dimensions



\* The dimensions of the heat resistance or fluororubber seal types are the same as those shown above.

**SMC** 


## Made to Order Individual Specifications MHZL2 Series



\* The dimensions of the heat resistance or fluororubber seal types are the same as those shown above.

D-🗆

# Parallel Type Air Gripper with Dust Cover **MHZJ2** Series ø6, ø10, ø16, ø20, ø25, ø32, ø40



#### Applicable Auto Switches/Refer to pages 797 to 850 for further information on the auto switch.


			light			I a salualita na		Load voltage			ch model	Lead	wire le	ength (	m) *	A	oplic	able	mod	el			
Туре	Special function	Electrical entry	ndicator	Wiring (Output)		uau vullay	e	Electrical en	try direction	0.5	1	3	5	ø6 ø	a10	a16	~20		Pre-wired connector		Applicable load		
	Idition	onay	ludic	(Output)		DC	AC	Perpendicular	In-line	(Nil)	(M)	(L)	(Z)	00	010	010	020	025		10	au		
				3-wire (NPN)				M9NV	M9N	•	٠	٠	0	٠	٠	٠	٠	٠	0				
				3-WIE (INFIN)		5 V. 12 V		F8N	—	•	—	٠	0	٠	-	۰	•	٠	-	IC			
_				3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	٠	0	٠	٠	٠	٠	•	0	circuit			
switch	_									F8P	_	•	-	٠	0	٠	-	٠	•	٠	-		
				2-wire		12 V		M9BV	M9B	٠	٠	٠	0	٠	٠	٠	•	٠	0		1		
auto			V		24 V	12 V		F8B	_	•	—	٠	0	٠	_	٠	•	•	-	_	Relay,		
state	Diagnosis	Grommet	res	3-wire (NPN)	24 V	5 V, 12 V	_	M9NWV	M9NW	•	•	٠	0	٠	٠	٠	٠	٠	0	IC	PLC		
l sta	(2-color			3-wire (PNP)		5 V, 12 V		M9PWV	M9PW	٠	•	٠	0	٠	٠	٠	•	٠	0	circuit			
Solid	indicator)			2-wire	1	12 V		M9BWV	M9BW	٠	٠	٠	0	٠	٠	٠	٠	٠	0	_	1		
05	Water resistant			3-wire (NPN)		EV 10.V		M9NAV**	M9NA**	0	0	•	0	٠	٠	٠	٠	٠	0	IC	]		
	(2-color			3-wire (PNP)		5 V, 12 V		M9PAV**	M9PA**	0	0	٠	0	٠	٠	٠	•	٠	0	circuit			
	indicator)			2-wire	1	12 V		M9BAV**	M9BA**	0	0	٠	0	٠	٠	٠	•	•	0	_	1		

\* Water resistant type auto s witches can be mounted \* Solid state auto switches marked with O are produced upon receipt of order. \* Lead wire length symbols: 0.5 m ..... Nil (Example) M9NW

1 m······ M (Example) M9NWM 3 m ...... L (Example) M9NWL

5 m ..... Z (Example) M9NWZ

Note 1) When using the 2-color indicator type, please make the setting so that the indicator is lit in red to ensure the detection at the proper position of the air gripper. Note 2) When using a D-F8D switch on sizes ø6, mount it at a distance of 10 mm or more from magnetic substances such as iron, etc. 440 **SMC** 





Symbol



Double acting: External grip

Single acting/

Normally open:

Single acting/ Normally closed: Internal grip



Ma Ol

S



	Made to Order Individual Specifications Refer to pages 451 to 453 for details.)
mbol	Specifications/Description

-X6100 With dust cover (ø32, ø40) Made to Order

#### Click here for detail

Click here for details					
Specifications/Description					
Heat resistance (100°C)					
Fluororubber seal					
Closing direction spring assist					
Opening direction spring assist					
Without magnet					
EPDM seal/Fluorine grease					
Axial ported type					
Fluorine grease					
Finger: Side tapped mounting					
Finger: Through-hole mounting					
Dust cover adhesion					
Dust cover adhesion (Finger part only)					
Dust cover caulking					
Dust cover caulking (Finger part only)					
Grease for food processing machines, Fluorine grease					
Grease for food processing machines					
Anti-corrosive treatment of finger					

#### Moisture Control Tube IDK Series

When operating an actuator with a small diameter and a short stroke at a high frequency, the dew condensation (water droplet) may occur inside the piping depending on the conditions.

Simply connecting the moisture control tube to the actuator will prevent dew condensation from occurring. For details, refer to the IDK series in the Best Pneumatics No. 6.

### Specifications

Fluid		d	Air			
			ø6: 0.15 to 0.7 MPa			
	Do	uble acting	ø10: 0.2 to 0.7 MPa			
Operating			ø16 to ø25: 0.1 to 0.7 MPa			
	0:	Normally open	ø6: 0.3 to 0.7 MPa			
	Single acting	~	ø10: 0.35 to 0.7 MPa			
	acting	Normally closed	ø16 to ø25: 0.25 to 0.7 MPa			
Ambient a	nd fluid	d temperature	-10 to 60°C			
Repeatabi	lity		±0.01 mm			
Max. opera	ating fr	equency	180 c.p.m.			
Lubrication			Not required			
Action			Double acting, Single acting			
Auto switch (option) Note)		on) <sup>Note)</sup>	Solid state auto switch (3-wire, 2-wire)			

Note) Refer to pages 797 to 850 for further information on auto switches.

#### Model

Action Model		-	Gripping f	Orce Note 1)	Opening/			
		Model	Model Bore size Gripping force per finger Effective value (N)			Closing stroke (Both sides)	Weight (g)	
			()	External	Internal	`(mm)		
		MHZJ2- 6D	6	3.3	6.1	4	28	
		MHZJ2-10D	10	9.8	17	4	60	
Double acting		MHZJ2-16D	16	30	40	6	130	
doung		MHZJ2-20D	20	42	66	10	250	
		MHZJ2-25D	25	65	104	14	460	I
	open	MHZJ2- 6S	6	1.9		4	28	
		MHZJ2-10S	10	6.3		4	60	Ì
	Normally	MHZJ2-16S	16	24	_	6	130	
	Ē	MHZJ2-20S	20	28		10	255	I
Single	ž	MHZJ2-25S	25	45		14	465	
acting	bed	MHZJ2- 6C	6		3.7	4	28	I
	closed	MHZJ2-10C	10		12	4	60	
		MHZJ2-16C	16	_	31	6	130	Ì
	Vormally	MHZJ2-20C	20		56	10	255	
	No	MHZJ2-25C	25		83	14	465	Ī

Note 1) Values based on pressure of 0.5 MPa, gripping point L = 20 mm, at center of stroke. Note 2) Values excluding weight of auto switch.

### Option

#### Body Option/End Boss Type

Symbol	Piping port		Type of piping port			Applicat	ole model	
Symbol	location	MHZJ2-10	J2-10 MHZJ2-16 MHZJ2-20 MHZJ2-25				Single acting	ſ
Nil	Basic type	M3 x 0.5	3 x 0.5 M5 x 0.8				•	
E	Side ported	M3 x 0.5	5 M5 x 0.8			•		ſ
w	Axial ported	With ø4 0	With ø4 One-touch fitting for coaxial tubing				—	
к	Axial ported	With ø4 One-touch fitting			-	•	ſ	
М	Axial ported	M5 x 0.8			—			

\* For detailed body option specifications, refer to option specifications on pages 449 and 450.

Refer to pages 454 to 458 for the specifications with auto switch.

· Auto switch installation examples and mounting positions

Auto switch hysteresis


· Auto switch mounting

· Protrusion of auto switch from edge of body


## MHZJ2 Series

### Construction: MHZJ2-6

### Double acting/With fingers open




#### Double acting/With fingers closed




#### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Piston	Stainless steel	
3	Lever	Stainless steel	Heat treated
4	Guide	Stainless steel	Heat treated
5	Finger	Stainless steel	Heat treated
6	Roller stopper	Stainless steel	
7	Lever shaft	Stainless steel	Nitriding
8	Magnet holder	Stainless steel	
9	Holder	Brass	Eiectroless nickel plated
10	Holder lock	Stainless steel	
11	Сар	Aluminum alloy	Clear anodized
12	Bumper	Urethane rubber	
13	Magnet	—	Nickel plated
14	Steel balls	High carbon chrome bearing steel	
15	Needle roller	High carbon chrome bearing steel	
		CR	
16	Dust cover	FKM	Fluororubber
		Silicone rubber	
17	Type C retaining ring	Carbon steel	Nickel plated
18	Exhaust plug	Brass	Electroless nickel plated
19	Exhaust filter	Polyvinyl formal	
20	N.O. spring	Stainless steel spring wire	
21	N.C. spring	Stainless steel spring wire	
22	Rod seal	NBR	
23	Piston seal	NBR	
24	Gasket	NBR	
25	Gasket	NBR	

#### Single acting/Normally open



#### Single acting/Normally closed



#### **Replacement Parts**

Descr	iptio	n	MHZJ2-6	Main parts		
Seal kit			Please contact SMC to replace the seal kit.			
	al	CR	MHZJ2-J6			
Dust cover	Material	FKM	MHZJ2-J6F	16		
	Ŵ	Silicone rubber	MHZJ2-J6S			
Finger assembly	Finger assembly			Please contact SMC to replace the finger assembly.		
	Μ	HZJ2-6D□	MHZJ-A0603	28910121315222324		
Piston assembly	Ν	IHZJ2-6S□	MH2J-A0603	2/8/9/0/2/3/0/2/2/2/2/		
	MHZJ2-6C□		MHZJ-A0603C	289101213152122 2329		

Replacement part/Grease pack part no.: GR-S-010 (5 g)

### **SMC**

Single acting/Normally open

Single acting/Normally closed

<u>nt</u>

ПП

(16

114


(17

 $\odot$ 


¢

#### Construction: MHZJ2-10□ to 25□

#### Double acting/With fingers open



#### Double acting/With fingers closed



#### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum alloy	Hard anodized
2	Piston	ø10, ø16: Stainless steel	ø20, ø25:
2	Piston	ø20, ø25: Aluminum alloy	Hard anodized
3	Lever	Stainless steel	Nitriding
4	Guide	Stainless steel	Heat treated
5	Finger	Stainless steel	Heat treated
6	Roller stopper	Stainless steel	
7	Lever shaft	Stainless steel	Nitriding
8	Сар	Aluminum alloy	Clear anodized
9	Bumper	Urethane rubber	
10	Rubber magnet	Synthetic rubber	
11	Steel balls	High carbon chrome bearing steel	

#### No. Description Material Note 12 Needle roller High carbon chrome bearing steel 13 Type C retaining ring Carbon steel Nickel plated Electroless nickel plated 14 Exhaust plug A Brass 15 Exhaust filter A Polyvinyl formal Stainless steel spring wire 16 N.O. spring 17 N.O. spring Stainless steel spring wire NBR 18 Rod seal Piston seal 19 NBR NBR 20 Gasket CR Chloroprene rubber 21 FKM Fluororubber Dust cover Silicone rubber

#### **Replacement Parts**

Description			MHZJ2-10	MHZJ2-16	MHZJ2-20	MHZJ2-25	Main parts
Seal kit			MHZJ10-PS	MHZJ16-PS	MHZJ20-PS	MHZJ25-PS	181920
	rial	CR	MHZJ2-J10	MHZJ2-J16	MHZJ2-J20	MHZJ2-J25	
Dust cover	Mater	FKM	MHZJ2-J10F	MHZJ2-J16F	MHZJ2-J20F	MHZJ2-J25F	20
	Σ	Silicone rubber	MHZJ2-J10S	MHZJ2-J16S	MHZJ2-J20S	MHZJ2-J25S	
Finger assembly			MHZJ-AA1002	MHZJ-AA1602	MHZJ-AA2002	MHZJ-AA2502	4561 Mounting thread
Piston assembly	issembly		MHZJ-A1003	MHZJ-A1603	MHZJ-A2003	MHZJ-A2503	291012
		MHZJ2-DDDW	MHZ-A1007	MHZ-A1607	MHZ-A2007	MHZ-A2507	Main hashes of adapted
End boss		MHZJ2-DDDDK	MHZ-A1008	MHZ-A1608	MHZ-A2008	MHZ-A2508	Main body of adaptor
assembly		MHZJ2-DDDDM	MHZ-A1009	MHZ-A1609	MHZ-A2009	MHZ-A2509	Mounting screw for adaptor Seal kit
		MHZJ2-DDDDE	MHZ-A1010	MHZ-A1610	MHZ-A2010	MHZ-A2510	Sear Kit
Lever assembly			MHZJ-A1004	MHZJ-A1604	MHZJ-A2004	MHZJ-A2504	37

\* Material of packing

NBR = Nitrile rubber, FKM = Fluororubber

\* Material of dust cover

CR = Chloroprene rubber, FKM = Fluororubber, Silicone rubber

\* End boss type

W = One-touching fitting for coaxial tubing, K = With One-touch fitting, M = With M5 port, E = Side ported

\* The end boss assembly other than type E should be mounted on the special body.



443 ®

 MHL

 MHR

 MHK

 MHS

 MHC

 MHT

 MHY

 MHW

 -X□

 MRHQ

 D-□


MHZ


MHF


## MHZJ2 Series

#### Dimensions

## MHZJ2-6 Double acting/Single acting Basic type









\* For single action, the port on one side is a breathing hole.

#### Auto Switch Mounting Groove Dimensions






Note) When using auto switches, through-hole mounting is not possible.


## MHZJ2 Series

#### Dimensions

## MHZJ2-16 Double acting/Single acting Basic type




MHZJ2-20 Double acting/Single acting Basic type



## MHZJ2 Series

Dimensions



448


**SMC** 

# With Dust Cover/MHZJ2 Series Body Option: End Boss Type

### **Applicable Model**

			Type of p	iping port		Applicable model		
Symbol	Piping port location	MHZJ2-10 MHZJ2-16		6 MHZJ2-20 MHZJ2-25		Double acting	Single	acting
		WH232-10	WI1232-10	WH232-20	WI1252-25	Double actility	Normally open	Normally closed
E	Side ported	M3 x 0.5	0.5 M5 x 0.8			•	•	•
w		With	With ø4 One-touch fitting for coaxial tubing				—	_
К	Axial ported	With ø4 One-touch fitting			—	•	•	
М			M5 x	< 0.8		_	•	


### Side Ported [E]



\* Refer to the dimension table.

\* When auto switches are used on ø10, side mounting with through-holes is not possible.

## Axial Ported (with One-touch fitting for coaxial tubing) [W]




\* Refer to the dimension table.

\* When auto switches are used on ø10, side mounting with through-holes is not possible.

### Changing from Coaxial to Single Tubing


Changing to single tubing is possible by using a branch "Y" or branch tee fitting.

In this case particularly, single tube fittings and tubing for ø3.2 will be necessary.



### Branch Tee, Different Diameter Tee, Branch "Y", Male Run Tee

Please contact your SMC sales representative for details of the coaxial fittings and tubing.



449 A

MHZ

MHF

MHL


MRHO

MA

D-

## MHZJ2 Series

## Axial Ported (with One-touch fitting) [K]



\* Refer to the dimension table

\* When auto switches are used on ø10, side mounting with through-holes is not possible

Note 1) Normally open type plug position.

Note 2) Normally closed type plug position.

The plug is mounted on only one side for the single acting type.

(mm) Model A в D1 D2 Е F G н MHZJ2-10<sup>S</sup>□K 15 7 12f8 -0.016 -0.043 40 5.5 11 16 28 MHZJ2-16<sup>S</sup>□K 20 10 16f8 -0.016 15 277 43.5 16.2 6.5 MHZJ2-20<sup>S</sup>□K 0 020 22 12 20f8 19 517 167 31.2 75 MHZJ2-25<sup>S</sup>□K 25 25f8 -0.020 -0.053 15 24 61.3 17.3 32.3 10

Other dimensions and specifications correspond to the standard type.

#### Applicable Tubing

Model

MHZJ2-10<sup>S</sup>□M

MHZJ2-16<sup>S</sup>□M

MHZJ2-20<sup>S</sup>CIM

MHZJ2-25<sup>S</sup>□M

Description/Model	Nylon tubing	Soft nylon tubing	tubing	Polyurethane coil tubing
Specifications Outside diameter (mm)	<b>T0425</b>	<b>TS0425</b>	TU0425	TCU0425B-1
Max. operating pressure (MPa)		0.8	0.5	0.5
Min. bending radius (mm)	13	12	10	_
Operating temperature (°C)	-20 to 60	-20 to 60	-20 to 60	-20 to 60
Material	Nylon 12	Nylon 12	Polyurethane	Polyurethane

Refer to "Pneumatic Piping Equipment (CAT, E50)" regarding One-touch fittings and tubing

16f8\_0.016

Other dimensions and specifications correspond to the standard type.

0.04

D2 Е F G

15 43.5 16.2 27.7 6.5

19 51.7 16.7 31.2 7.5

в D1

Α

15 7 12f8 -0.016 11 40 16 28

20 10

22 12 20f8 -0.020

25 15 25f8 -0.020 24 61.3 17.3 32.3 10

(mm)

н

5.5

#### Auto switch mounting Plug groove (4 locations) End boss assembly ø10 · M-3P (Except ø10) ø16 to 25: M-5P G Note ØD2 г÷т Ð φ ē ÷ E nte 2 5 в H, F Auto switch mounting groove (Both sides) (ø10 only: Round groove) M5 x 0.8 Piping port

\* Refer to the dimension table

\* When auto switches are used on ø10, side mounting with through-holes is not possible

Note 1) Normally open type plug position.

Note 2) Normally closed type plug position.

The plug is mounted on only one side for the single acting type.

### Weight


				(g)				
Model		End boss type (Symbol)						
woder	E	w	к	М				
MHZJ2-10	70	70	70	70				
MHZJ2-16	165	165	165	165				
MHZJ2-20	290	290	290	290				
MHZJ2-25	525	525	525	525				

## Axial Ported (with M5 port) [M]

# **MHZJ2** Series Made to Order Individual Specifications

Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.



#### Specifications

Mc	del	Basic type	Heat resistance	Fluororubber seal	
Fluid			Air		
Operating pressure	Double acting	0.1 to 0.7 MPa			
Ambient and flu	id temperature	-10 to 60°C	-10 to 100°C	-10 to 60°C	
Repeatability			±0.01 mm		
Max. operating	frequency		60 c.P.m		
Lubrication		Not required			
Action		Double acting			

#### Model

Action	Model	Bore size (mm)	Gripping f	orce Note 1)	Opening/	
			Gripping force per finger Effective value (N)		Closing stroke (Both sides)	Note 2) Weight (g)
			External	Internal	(mm)	
Double	MHZJ2-32D-X6100	32	158	193	22	760
acting	MHZJ2-40D-X6100	40	254	318	30	1325

Note 1) Values based on pressure of 0.5 MPa, gripping point L = 20 mm, at center of stroke.

Note 2) Values excluding weight of auto switch.

451 @

#### 🗥 Handling Precautions

#### Heat resistance

#### A Warning

Be aware that smoking cigarettes after your hands have come into contact with the grease used for this air gripper can create a gas that is hazardous to humans.

#### ▲ Caution

- Note 1) Magnet is built-in, but when using an auto switch, the acceptable temperature range becomes -10 to 60°C.
- Note 2) With the part number for the dust cover option, only fluororubber (F) or silicone rubber (S) options may be selected.

Note 3) For lubrication, specialized grease GR-F is recommended.

#### ▲ Caution

Note 1) Please contact SMC, since the type of chemical and the operating temperature may not allow the use of this product.


Fluororubber seal

- Note 2) Since the standard-type magnet is built-in, please contact SMC for the product's adaptability to the operating environment.
- Note 3) For the air gripper with a dust cover, the dust cover material is also fluororubber. Thus, enter (F) for the fluororubber dust cover in the part number.

## MHZJ2 Series

Dimensions (Dimensions other than specified below are the same as the standard type.)

#### MHZJ2-32D□-X6100 Basic type/Double acting




\* The dimensions of the heat resistance or fluororubber seal types are the same as those shown above.

**SMC** 

Dimensions (Dimensions other than specified below are the same as the standard type.)

#### MHZJ2-40D□-X6100 Basic type/Double acting



## MHZ2/MHZ 2 Series Auto Switch Installation Examples and Mounting Position

Various auto switch applications are possible through different combinations of auto switch quantities and detecting positions. 1) Detection when Gripping Exterior of Workpiece

Detection example	1. Confirmation of fingers in reset position	2. Confirmation of workpiece held	3. Confirmation of workpiece released	
Position to be detected	Position of fingers fully opened	Position when gripping workpiece	Position of fingers fully to the second seco	
Operation of auto switch	Auto switch turned on when fingers return. (Light ON)	Auto switch turned on when gripping a workpiece. (Light ON)	When a workpiece is not held (Abnormal operation): Auto switch to turn ON (Light ON)	
So Dre auto switch *One position, any of ①, ②, and ③ can be detected. Two positions of *Two positions of be detected. B B C C C C C C C C C C C C C	•	•	•	
S Two auto switches	•	•	—	
*Two positions of 1, 2, and 3 can be detected		•	•	
be detected.	•	_	•	
How to determine auto switch installation position	Step 1) Fully open the fingers.	Step 1) Position fingers for gripping a workpiece.	Step 1) Fully close the fingers.	
At no pressure or low	Step 2) Insert the auto switch into the sw	itch installation groove in the direction sh	own in the following drawing.0	
pressure, connect the auto switch to a power supply, and follow the directions.				
	Step 3) Slide the auto switch in the direction of the arrow until the indicator light illuminates.	Step 3) Slide the auto switch in the dirr fasten it at a position 0.3 to 0.5 mm in where the indicator light illuminates.	action of the arrow until the light illuminates and the direction of the arrow beyond the position	
		Position where light turns	ON	
	Step 4) Slide the auto switch further in the direction of the arrow until the indicator light goes out.		<u>₩□€</u> #@ <u> -</u>	
	Step 5) Move the auto switch in the	0.	3 to 0.5 mm	
	opposite direction and fasten it at a position 0.3 to 0.5 mm beyond the position where the indicator light illuminates.	Position to be secured		
	Position where light turns ON			
	Position to be secured			

Note 1) It is recommended that gripping of a workpiece be performed close to the center of the finger stroke.

Note 2) When holding a workpiece close at the end of open/close stroke of fingers, detecting performance of the combinations listed in the above table may be limited, depending on the hysteresis of an auto switch, etc.

SMC SMC

## Parallel Type Air Gripper MHZ2, MHZ 2 Series

Various auto switch applications are possible through different combinations of auto switch quantities and detecting positions. 2) Detection when Gripping Interior of Workpiece

Detection example	1. Confirmation of fingers in reset position	2. Confirmation of workpiece held	3. Confirmation of workpiece released				
Position to be detected	Position of tingers fully closed	Position when gripping workpiece	Position of fingers fully opened				
Operation of auto switch	Auto switch turned ON when fingers return. (Light ON)	Auto switch turned ON when gripping a workpiece. (Light ON)	When a workpiece is not held (Abnormal operation): Auto switch to turn ON (Light ON)				
See of the sector of	•	•	•				
Two auto switches Two positions of (1, 2), and (3) can be detected.	-	•	•				
be detected.	•	_	•				
How to determine auto switch installation position	Step 1) Fully close the fingers.	Step 1) Position fingers for gripping workpiece.	Step 1) Fully open the fingers.				
At no pressure or low	Step 2) Insert the auto switch into the sw	itch installation groove in the direction sh	l nown in the following drawing.	MHZ			
pressure, connect the auto switch to a power supply, and follow the							
directions.							
	Step 3) Move the auto switch in the direction of the arrow until the indicator light illuminates. Step 3) Slide the auto switch in the direction of the arrow until the indicator light illuminates.						
	Position where light turns ON	Step 4) Slide the auto switch further light goes out.	in the direction of the arrow until the indicator	MHC Mht			
				MHY			
	0.3 to 0.5 mm	T		MHW			
	secured		he opposite direction 0.3 to 0.5 mm in the its location when the indicator light comes on	-X□			
	<b>→</b>	ayam.		MRHQ			
		Position where light turns ON		MA			
		↓ <u>←</u>	0.3 to 0.5 mm	D-			
		Position to be secured					
		• · · · ·					

Note 1) It is recommended that gripping of a workpiece be performed close to the center of the finger stroke.


Note 2) When holding a workpiece close at the end of open/close stroke of fingers, detecting performance of the combinations listed in the above table may be limited, depending on the hysteresis of an auto switch, etc.

## MHZ2, MHZ 2 Series

#### **Auto Switch Hysteresis**

Auto switches have hysteresis similar to micro switches.

Use the table below as a guide when adjusting auto switch positions, etc.



#### Hysteresis


Auto switch model	D-Y59A/Y59B D-Y69A/Y69B D-Y7P(V) D-Y7□W(V)	D-F8□	D-M9□(V) D-M9□W(V) D-M9□A(V)
MHZ2-6	No setting	0.5	0.5
MHZ2-10, MHZL2-10	0.5	No setting	0.5 Note)
MHZ2-16 , MHZL2-16	0.5	0.5	0.5
MHZ2-20 , MHZL2-20	0.5	0.5	0.8
MHZ2-25 , MHZL2-25	0.5	0.5	0.5
MHZ2-32	0.5	0.5	0.7
MHZ2-40□	0.5	0.5	0.9
MHZJ2-6		0.5	0.5
MHZJ2-10		0.5	0.5
MHZJ2-16□	No setting	0.5	0.5
MHZJ2-20		0.5	0.8
MHZJ2-25		0.5	0.5

Note) When mounting D-M9□(V), M9□W(V) and M9□A(V) on MHZ2-10□ and MHZL2-10, mounting brackets (BMG2-012) are required.

#### **Auto Switch Mounting**

#### Applicable models: MHZ2-6 MHZJ2 Series Round groove of the MHZ2 series Round groove of the MHZL2 series

To set the auto switch, insert the auto switch into the auto switch installation groove of the gripper from the direction indicated in the following drawing. After setting the position, tighten the attached auto switch mounting screw with a flat head watchmaker's screwdriver.



Note) Use a watchmaker's screwdriver with a grip diameter of 5 to 6 mm to tighten the auto switch mounting screw. The tightening torque should be 0.05 to 0.15 N·m.


#### [Mounting of Auto Switch: Precautions]

When mounting an auto switch on the piping port surface of the MHZJ2-10□, the auto switch may not be mountable due to interference with the fitting. Use an extension fitting included with the product for the combinations in the table below.

Auto switch model	One-touch Mini Fittings (KQ2H/KQ2S/KQ2L/KQ2W) KJH/KJS/KJL/KJW	
D-M9□(V)	×	
D-M9⊟W(V)	×	N
D-F8	×	()
D-M9□A(V)	×	1




#### Mounting dimensions of extension fitting



#### Applicable models:

#### Square groove on the side of the MHZ2 series Square groove on the side of the MHZL2 series

- To set the auto switch, insert the auto switch into the installation groove of the cylinder as shown below and set it roughly.
- (2) Insert the auto switch into the auto switch bracket installation groove.
- (3) After confirming the detecting position, tighten the set screws (M2.5) attached to the auto switch and set it.
- (4) Be sure to change the detecting position in the state of (2).




Auto Switch Mountin	Auto Switch Mounting Bracket: Part No.					
Auto switch part no.	Auto switch mounting bracket part no.					
D-M9□(V) D-M9□W(V) D-F8□ D-M9□A(V)	BMG2-012					

- Note) Use a watchmaker's screwdriver with a grip diameter of 5 to 6 mm to tighten the set screws (M2.5).
  - The tightening torque should be 0.05 to 0.1 N·m.
  - As a guide, it should be turned about 90° beyond the point at which tightening can be felt.

Note) D-F8□ cannot be mounted on MHZ2-10□, MHZJ2-10□ and MHZL2-10□

#### [Handling of Mounting Brackets: Precautions]

When auto switch is set on the mounting side as shown below, allow at least 2 mm run off space on mounting plate since the auto switch is protruded from the gripper edge.



 MHZ

 MHF

 MHL

 MHR

 MHR

 MHR

 MHK

 MHK

 MHK

 MHK

 MHK

 MHK

 MHQ

 MA

 D-□

## MHZ2, MHZ 2 Series

### Protrusion of Auto Switch from Edge of Body

The amount of auto switch protrusion from the body's end surface is as shown in the table below.

Use this as a standard when mounting, etc.

D-F8 has no protrusion from the body's end surface.

The end boss type has no protrusion either.

#### Standard Body

Explanatory drawing         D-YS9: D-Y7P         D-M9: D-M9: Marginger         D-Y99: D-Y7PV         D-M9: D-M9: D-Y7PV         D-M9: D-Y7PV         D-M9: D-Y7PV         D-Y7PV         D-M9: D-Y7PV        <	Lead wire type		In-line electric	cal entry type		Perpendicular electrial entry type				
HITZ2-6:         Open	V >	Evaluation		natory			ศ			
No setting         D-YS90 D-Y7P D-	$  \rangle$							Ц		
No.def         D-Y7_IW         D-M9_W         D-Y7_IWV         D-M9_WV         V         M9_UVV           MHZ2-60         Open         11         13         15         No setting         11         13         15         No setting         11         13         No setting         01         13         No setting         01         13         No setting         01         11         13         10         11         13         10         11         13         10         11         13         10         11         13         10         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         13         15         15         7         11         13         11         13										
No.def         D-Y7_IW         D-M9_W         D-Y7_IWV         D-M9_WV         V         M9_UVV           MHZ2-60         Open         11         13         15         No setting         11         13         15         No setting         11         13         No setting         01         13         No setting         01         13         No setting         01         11         13         10         11         13         10         11         13         10         11         13         10         11         13         10         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         13         15         15         7         11         13         11         13	$  \rangle$					L	-+-+-			
No.def         D-Y7_IW         D-M9_W         D-Y7_IWV         D-M9_WV         V         M9_UVV           MHZ2-60         Open         11         13         15         No setting         11         13         15         No setting         11         13         No setting         01         13         No setting         01         13         No setting         01         11         13         10         11         13         10         11         13         10         11         13         10         11         13         10         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         13         15         15         7         11         13         11         13	\	1		.	L		L.		L	
No.def         D-Y7_IW         D-M9_W         D-Y7_IWV         D-M9_WV         V         M9_UVV           MHZ2-60         Open         11         13         15         No setting         11         13         15         No setting         11         13         No setting         01         13         No setting         01         13         No setting         01         11         13         10         11         13         10         11         13         10         11         13         10         11         13         10         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         13         15         15         7         11         13         11         13		\	1 2	$\sum$					4-1-1	
No.def         D-Y7_IW         D-M9_W         D-Y7_IWV         D-M9_WV         V         M9_UVV           MHZ2-60         Open         11         13         15         No setting         11         13         15         No setting         11         13         No setting         01         13         No setting         01         13         No setting         01         11         13         10         11         13         10         11         13         10         11         13         10         11         13         10         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         13         15         15         7         11         13         11         13		1		3			<u>+</u>			-
No.def         D-Y7_IW         D-M9_W         D-Y7_IWV         D-M9_WV         V         M9_UVV           MHZ2-60         Open         11         13         15         No setting         11         13         15         No setting         11         13         No setting         01         13         No setting         01         13         No setting         01         11         13         10         11         13         10         11         13         10         11         13         10         11         13         10         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         13         15         15         7         11         13         11         13			10	100				D VOO		
No.def         D-Y7_IW         D-M9_W         D-Y7_IWV         D-M9_WV         V         M9_UVV           MHZ2-60         Open         11         13         15         No setting         11         13         15         No setting         11         13         No setting         01         13         No setting         01         13         No setting         01         11         13         10         11         13         10         11         13         10         11         13         10         11         13         10         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         11         13         13         15         15         7         11         13         11         13			Air grippor	\$\ <sup>®</sup>						
MH22-60         Open Close         No setting 11         11 13         13 15         No setting 11         11 13           MH22-100         Open Close         7.5         6.5 km 3 8.5 km 3 10         5.5 km 3 8.5 km 3 8.5 km 3 10         -         1.5 km 3 11         13 13           MH22-100         Open Close         0.6         4.6         5.2         4.5 km 3 8.5 km 3 10         -			model	2		D-M9⊡W	D-INIS		D-M9□WV	D-WISLAV
MH22-C:         Closes         No setting         13         15         No setting         11         13           MHZ2-10:         Open         1         3.5 km 3         5.5 km 3         6.5         4.6 km 3         6.5 km 3         7 km 3         5 km 3 <t< td=""><td></td><td></td><td><u>`</u></td><td></td><td>01181</td><td>11</td><td>13</td><td></td><td>9</td><td>11</td></t<>			<u>`</u>		01181	11	13		9	11
MH22-10:         Open         1         3.5 km 3)         5.5 km 3)         6.5         4.5 km 3)         3.5 km 3)         6.5           MH22-16:         Open          1         3			MHZ2-6		No setting			No setting		
MH22-10         Close         7.5         6.5 % % 3         8.6 % 3         6.5         4.5 % 7         6.5 % 7           MHZ2-16         Open          1         3              MHZ2-20         Open  -					1			_		
MHZ2-16:         Open          1         3             MHZ2-10:         Open                MHZ2-20:         Open                 MHZ2-20:         Open			MHZ2-10□			6.5 Note 3)		6.5	4.5 <sup>Note 3)</sup>	6.5 <sup>Note 3)</sup>
MH22-16         Close         6         4         6         5         2         4           MHZ2-20         Close         A         2         A         3 <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>_</td><td>_</td></t<>									_	_
MHZ2-20         Open         -	7	5	MHZ2-16□	<u> </u>				5	2	4
MH22-25         Close         1	2	đ			_	_	_	_		
MH22-25         Close         1	5	Ē	MHZ2-20		4	2	4	3		_
MH22-25         Close         1	+	0 0						_		_
MHZ2-32:         Open Close			MHZ2-25		1	_	_	_		_
MH22-32         Close         3           2             MHZ2-40         Open						_	_	_	_	_
MHZ2-40         Open Close			MHZ2-32		3	_	_	2	_	_
MHZ2-40         Close         2         -         -         1         -         -           MHZJ2-60         Open Close         Open Close         11         13         15         3         5           MHZJ2-100         Open Close         Open Close         7         9         11         13         3         5           MHZJ2-200         Open Close         Open Close         -						_	_	_	_	_
MHZJ2-60         Open Close         11         13         15           MHZJ2-100         Open Close         No setting         5         7         9           MHZJ2-200         Open Close         MHZJ2-200         Open Close         No setting         5         7           MHZJ2-200         Open Close         Open Close         0         0.5         1.5 MMB 3         3.5 MMB 3         -         -         -           MHZL2-10D         Open Close         0.5         1.5 MMB 3         3.5 MMB 3         -         -         -         -           MHZL2-10D         Open Close         0.5         1.5 MMB 3         3.5 MMB 3         -         -         -         -           MHZL2-10D         Open         0.5         1.5 MMB 3         3.5 MMB 3         -			MHZ2-40		2	_	_	1	_	_
MHZJ2-0         Close Open (Close         13         15 5         7         9           MHZJ2-100         Close Open (Close         Open (Close         Open (Close         11         13         15           MHZJ2-200         Open (Close         No setting         2         4			MHZJ2-6□			11	13		9	11
MHZJ2-10:         Open Close         So setting         S         7         9           MHZJ2-16:         Open Close         Open Close         Open Close         No setting         2         4           MHZJ2-20:         Close Close         Open Close         Open Close             MHZJ2-20:         Close Close         Open Close         0.5         1.5 Mole 3         3.5 Mole 3           MHZL2-10D         Open Close         0.5         1.5 Mole 3         3.5 Mole 3            MHZL2-10D         Open Close         0.5         1.5 Mole 3         7.5         6 Note 3         8 Note 3           MHZL2-20D         Open                MHZL2-20D         Open                MHZL2-20D         Open                MHZL2-20D         Open                MHZL2-20D         Open                MHZL2-20D         Open            -						13	15			13
MHZJ2-250         Open Glose         —         …	3	e	MHZJ2-10			5	7	1	3	5
MHZJ2-250         Open Glose         —         …		§.				7	9		5	7
MHZJ2-250         Open Glose         —         …		5	MHZJ2-16□	Open		2	4	No setting 3	_	_
MHZJ2-250         Open Glose         —         …		Ĩ			No setting	5	7		3	5
MHZJ2-250         Open Glose         —         …		_		Open		_	_		_	-
MHZJ2-250         Open Glose         —         …	1014	ž	MHZJ2-20	Close		3	5		1	3
MHZL2-10D         Open         0.5         1.5 Mob 3)         3.5 Mob 3)             MHZL2-10D         Open         0.5         1.5 Mob 3)         10         Note 3)         7.5         6 Note 3)         8 Note 3)           MHZL2-10D         Open                 MHZL2-20D         Open                 MHZL2-20D         Open                 MHZL2-20D         Open                 MHZL2-20D         Open                 MHZL2-20D         Open                 MHZL2-10S         Open </td <td>-</td> <td>~</td> <td></td> <td>Open</td> <td></td> <td>_</td> <td>—</td> <td></td> <td>_</td> <td>_</td>	-	~		Open		_	—		_	_
MHZL2-10D         Ciose         8.5         8         Note 3         7.5         6         Note 3         9         Note 3           MHZL2-10D         Open				Close			4		-	_
Open   -				Open	0.5	1.5 Note 3)	3.5 <sup>Note 3)</sup>	-	-	_
MHZL2-20D         Open		0		Close	8.5	8 Note 3)	10 Note 3)	7.5	6 Note 3)	8 Note 3)
MHZL2-20D         Open		Ē		Open	—	—	—	—	—	_
MHZL2-20D         Open		ac	WITZL2-10D	Close	8	6	8	7	4	6
MHZL2-25D         Close         5.5         3.5         5.5         4.5         1.5         3.5           MHZL2-10S         Open         —         …		le	MH71 2-20D		_	-		_	_	_
MHZL2-25D         Close         5.5         3.5         5.5         4.5         1.5         3.5           MHZL2-10S         Open         —         …		nr Dr	WITZL2-20D	Close	7	5	7	6	3	5
MHZL2-10S         Open		ă	MH71 2-25D	Open		_			_	_
MHZL2-10C         Open			MILL2-200	Close	5.5	3.5	5.5	4.5	1.5	3.5
MHZL2-10C         Open		(ue	MH71 2-109			_				
MHZL2-10C         Open	e	y op	MITZE2-105	Close		_			_	_
MHZL2-10C         Open	8	mall	MH71 2-165	Open	-		_	_	-	_
MHZL2-10C         Open	str	Non			3	1	3	2	-	_
MHZL2-10C         Open	b	) Bu	MHZI 2-205		_	_	_	_	_	_
MHZL2-10C         Open	P.	acti	11112L2-203		1	-	_	_	-	_
MHZL2-10C         Open		ngle	MH71 2-255			_	_		_	_
MHZL2-10C         Open         - <t< td=""><td></td><td></td><td>IIII 122-233</td><td></td><td>-</td><td>_</td><td>-</td><td>-</td><td>-</td><td>_</td></t<>			IIII 122-233		-	_	-	-	-	_
MHZL2-16C         Close         5.5         5 Note3)         7 Note3)         4.5         3 Note3)         5 Note3)           MHZL2-16C         Open <th< td=""><td></td><td>Sed)</td><td>MHZL2-10C</td><td></td><td>—</td><td>_</td><td></td><td></td><td></td><td>_</td></th<>		Sed)	MHZL2-10C		—	_				_
MHZL2-16C         Open         - <t< td=""><td></td><td>clo</td><td></td><td></td><td></td><td></td><td></td><td></td><td>3 Note 3)</td><td>5 Note 3)</td></t<>		clo							3 Note 3)	5 Note 3)
Bit Mitzle         Close         5.5         3.5         5.5         4.5         1.5         3.5           MHZL2-20C         Open <t< td=""><td></td><td>mally</td><td>MHZL2-16C</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>		mally	MHZL2-16C							
MHZL2-20C         Open         - <t< td=""><td></td><td>Nor</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>		Nor								
Image: Close         3.5         1.5         3.5         2.5             Image: MHZL2-25C         Open		) Bu	MHZL2-20C						-	_
B         MHZL2-25C         Open         - <t< td=""><td></td><td>acti</td><td></td><td></td><td></td><td></td><td></td><td>2.5</td><td></td><td></td></t<>		acti						2.5		
Image: Close         1.5         -         -         0.5         -         -		ngle	MHZL2-25C							_
		S		Close	1.5	-	_	0.5	-	-

Note 1) There is no protrusion if no values are entered in the table. Note 2) The actual mounting position should be adjusted after confirming the auto switch operating conditions. Note 3) When mounting D-MB([V], MS\_W(V) and MS\_DA(V) on MH22-10[] and MH2L2-10, mounting brackets (BMG2-012) are required.

# *MHZ2 Series* Made to Order: Individual Specifications 1

Ī


Ì



### 1 Built-in needle valve for finger speed control

Symbol -X46


Installation of a variable throttle allows adjustment of the finger opening/closing speed.



Bore size (mm)	10, 16, 20, 25			
Action	Double acting			
Needle position	Refer to the dimensions and figures below.			
Specifications/dimensions other than the above Same as the standard type				
Note) Not evolupie for a gaza and gaza				

Note) Not available for ø6, ø32 and ø40.

Dimensions (Dimensions other than specified below are the same as the standard type.)



Adjust so that the finger opening/closing speed will be no greater than necessary. If the finger opening/closing speed is greater than necessary, impact forces acting on the fingers and other parts will increase. This can cause a loss of repeatability when gripping workpieces and have an adverse effect on the life of the unit.

This needle is used to adjust the finger closing speed. When adjusting the opening speed (attenuating impact during operation, etc.), use a meter-out control speed controller AS series.

#### Guide for Internal Needle Adjustment

Model	Number of rotations from fully closed needle condition Note)
MHZ2-10D -X46	1/4 to 1/2
MHZ2-16D -X46	1/2 to 1
MHZ2-20D -X46	1 to 1 <sup>1</sup> /2
MHZ2-25D -X46	11/2 to 2

Note) The condition in which the needle is tightened gently until it stops.

				(mm)	MHF
Model	Α	В	С	D *	
MHZ2-10D -X46	9	11	4.5	5.2	MHL
MHZ2-16D -X46	7.5	13	7	5.8	<u> </u>
MHZ2-20D -X46	10	15	7	6	MHR
MH72-25D	10.7	20	7	6.2	

Dimensions other than the above are identical to the standard type; refer to pages 417 to 420.

\* Reference values to establish criteria for needle adjustment.

MHZ
MHF
MHL
MHR
MHK
MHS
MHC
MHT
MHY
MHW
-X□
MRHQ
MA
D-🗆


# MHZ2 Series Made to Order: Individual Specifications 2



### 2 MHQ2/MHQG2 Compatible Flat Type Fingers

Symbol -X51

Previous MHQ2/MHQG2 series compatible flat type finger is selectable for the MHZ2 series.




Bore size (mm)	10, 16, 20, 25
Action	Double acting, Single acting (normally open, normally closed)
Finger dimensions	Refer to the dimensions and figures below.
Specifications/dimensions other than the above	Same as the standard type

Note 1) Not available for ø6, ø32 and ø40.

Note 2) An option symbol (3) for the flat finger type is not specified.

**Dimensions** (Dimensions other than specified below are the same as the standard type.)



										(mm)
Model		A B C		D	G					
IVIOU	ei	Α	P	с		Open Closed MM L		w		
MHZ2-10□□-X51	MHQG2 compatible	3	6	5.2	12	9.7 +2.2	5.7 _0.4	M2 x 0.4	3.6	5 -0.05
	MHQ2 compatible	2	5	5.2	9	9.7 0 2.2	5.7 -0.4	M2 x 0.4	3.6	5-0.05
MHZ2-16□□-X51	MHQG2 compatible	4	8	8.3	16	12.6 +2.2	6.6 <sup>0</sup> <sub>-0.4</sub>	M3 x 0.5	6	8 -0.05
	MHQ2 compatible	2.5	7	8.3	12	12.6 +2.2	6.6 _0.4	M3 x 0.5	6	8 -0.05
MHZ2-20	MHQG2 compatible	5	10	10.5	20.8	17.2 +2.2	7.2 -0.4	M4 x 0.7	8	10 -0.05
	MHQ2 compatible	3.3	9	10.5	15.5	17.2 +2.2	7.2 _0.4	M4 x 0.7	8	10_0.05
	MHQG2 compatible	6.5	12	13.1	25	22.8 +2.5	8.8 -0.4	M5 x 0.8	10	12-0.05
MHZ2-25	MHQ2 compatible	3.5	12	13.1	19	22.8 0 +2.5	8.8 -0.4	M5 x 0.8	10	12-0.05

460

**SMC** 



## MHZ Series Specific Product Precautions


Be sure to read this before handling the products.

### Mounting Air Grippers/MHZ 2 Series

Possible to mount from 3 directions.

#### How to mount air grippers

#### Axial mounting (Body tapped)




Model	Applicable bolts	Max. tightening torque (N·m)	Max. screw-in depth (L mm)
MHZ_2-6 <sup>Note)</sup>	M2 x 0.4	0.15	4.5
MHZ_2-10	M3 x 0.5	0.88	6
MHZ_2-16	M4 x 0.7	2.1	8
MHZ_2-20	M5 x 0.8	4.3	10
MHZ_2-25	M6 x 1	7.3	12
MHZ_2-32	M6 x 1	7.9	13
MHZ_2-40	M8 x 1.25	17.7	17

Note) Axial mounting type is not available for MHZ2-6 and MHZJ2-6.

Model	Hole diameter (mm)	Hole depth (mm)
MHZ[]2- 6	ø7H8 <sup>+0.022</sup>	1.5
MHZ_2-10	ø11H9 <sup>+0.043</sup>	2
MHZ_2-16	ø17H9 <sup>+0.043</sup>	2
MHZ_2-20	ø21H9 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	3
MHZ_2-25	ø26H9 <sup>+0.052</sup>	3.5
MHZ_2-32	ø34H9 <sup>+0.062</sup>	4
MHZ_2-40	ø42H9 <sup>+0.062</sup>	4

#### Perpendicular mounting (Body tapping)




Model	Applicable bolts	Max. tightening torque (N·m)	Max. screw-in depth (L mm)				
MHZ 2-6Note	M2 x 0.4	0.15	4				
MHZ_2-10	M3 x 0.5	0.9	6				
MHZ_2-16	M4 x 0.7	1.6	4.5				
MHZ_2-20	M5 x 0.8	3.3	8				
MHZ_2-25	M6 x 1	5.9	10				
MHZ_2-32	M6 x 1	5.9	10				
MHZ_2-40	M8 x 1.25	13.7	13				
Nete) Event MUZO O and MUZIO O							

Note) Except MHZ2-6 and MHZJ2-6.


#### How to mount air grippers

Lateral mounting (Body tapped and through-hole) •Body tapped



Model	Applicable bolts	Max. tightening torque (N·m)	Max. screw-in depth (L mm)
MHZ_2-6	M3 x 0.5	0.88	10
MHZ_2-10	M3 x 0.5	0.69	5
MHZ_2-16	M4 x 0.7	2.1	8
MHZ_2-20	M5 x 0.8	4.3	10
MHZ_2-25	M6 x 1	7.3	12
MHZ_2-32	M6 x 1	7.9	13
MHZ_2-40	M8 x 1.25	17.7	16

#### Body through-holes




Model	Applicable bolts	Max. tightening torque (N·m)
MHZ_2-6	M2.5 x 0.45	0.49
MHZ[2-10	M2.5 x 0.45	0.49
MHZ_2-16	M3 x 0.5	0.88
MHZ[2-20	M4 x 0.7	2.1
MHZ_2-25	M5 x 0.8	4.3
MHZ_2-32	M5 x 0.8	4.3
MHZ_2-40	M6 x 1	7.3

Note) Use body tapped for D-Y59, D-Y69, D-Y7P with auto switch types. Make sure that the bolt's screw-in depth is less than those shown in the table below to prevent the tip of the bolt from pressing the switch body.

Model	Max. screw-in depth (L mm)
MHZ_2- 6	_
MHZ_2-10	5
MHZ_2-16	8
MHZ_2-20	10
MHZ_2-25	12
MHZ_2-32	13
MHZ_2-40	16

#### How to mount the attachment to the finger

The attachment must be mounted on fingers using bolts such as finger mounting female threads, etc., which should be tightened with the tightening torque in the table below.



			MI17
Model	Applicable bolts	Max. tightening torque (N·m)	MHZ
MHZ_2- 6		0.15	MULE
MHZ_2-10		0.31	MHF
MHZ_2-16	M3 x 0.5	0.59	
MHZ_2-20	M4 x 0.7	1.4	MHL
MHZ_2-25	M5 x 0.8	2.8	
MHZ_2-32	M6 x 1	4.9	MHR
MHZ_2-40	M8 x 1.25	11.8	
			MHK
			MHS
			MHC
			MHT
			MHY
			MHW
			-X□
			MRHQ
			MA
			D-□
			·

**Operating Environment** 

## ▲ Caution

#### Use caution for the anti-corrosiveness of linear guide section.

Martensitic stainless steel is used for the finger guide. But, use caution that anti-corrosiveness is inferior to the austenitic stainless steel. Especially, in an environment where waterdrops are adhered by condensation, etc., rust might be generated.

#### **SMC**

# High Rigidity MHQG2 Series Ø32, Ø40

#### With guide holder

Possible to mount the solid state auto switch with indicator light.



#### Specifications

Fluid			Air	
Operating Double act	le acting	0.1 to 0.6 MPa		
Operating pressure Single Normally open 0.25				
pressure	acting Normally closed	0.25 to 0.6 MPa		
Ambient an	d fluid tem	perature	-10 to 60°C	
Repeatabilit	y		ø32, 40: ±0.02 mm	
Max. operat	ing freque	ncy	ø32, 40: 60 c.p.m	
Lubrication			Not required	
Operating s	ystem		Double acting, Single acting	
Auto switch (Option) *			Solid state auto switch: D-M9N(V), D-M9P(V), D-M9B(V), D-Y59_{B}^{\rm A}, D-Y69_{B}^{\rm A}	

\* Refer to pages 797 to 850 for the detailed specifications of auto switches.

#### Model

Operating system Mo		Model	Cylinder bore (mm)	Gripping force <sup>Note 1)</sup> (Effective value) N	Opening/Closing stroke (mm)	Weight (g)
		MHQG2-32D	32	External grip: 88 Internal grip: 139	20	1100
Doubi	Double acting		40	External grip: 158 Internal grip: 247	28	1940
	Normally	MHQG2-32S	32	69	20	1110
Single	Single open	MHQG2-40S	40	130	28	1960
acting Normally	MHQG2-32C	32	127	20	1110	
	closed	MHQG2-40C	40	227	28	1960

Note 1) Values at the pressure of 0.5 MPa. Double acting is compatible with both external and internal gripping forces, while single acting and normally open external gripping force, and single acting and normally closed internal gripping force.

Note 2) Values excluding weight of auto switch.

Symbol

Double acting: External grip

Double acting: Internal grip

Single acting/Normally closed: Internal grip



Single acting/Normally open: External grip



# With Dust Cover **MHQJ2** Series Ø10, Ø16, Ø20, Ø25

Air gripper with dustproof and dripproof construction

Enclosure to prevent accumulation of dust.

Sealed construction with a dust cover

Possible to mount the solid state auto switch with indicator light.

# Three-type dust cover variations for diversified applications



#### Symbol

Double acting: Internal grip



Double acting: External grip

Single acting/Normally closed: Internal grip



Single acting/Normally open: External grip



### Specifications

Fluid			Air			
• •	Double acting		0.1 to 0.6 MPa			
Operating pressure	ing Single Normally	Normally open				
pressure	acting	Normally closed	0.25 to 0.6 MPa			
Ambient and	d fluid tem	perature	-10 to 60°C			
Repeatabilit	у		±0.01 mm			
Max. operati	ing freque	ıcy	180 c.p.m			
Lubrication			Not required			
Operating system			Double acting, Single acting			
Auto switch (Option) *			Solid state auto switch: D-M9N(V), D-M9P(V), D-M9B(V)			

\* Refer to pages 797 to 850 for the detailed specifications of auto switches.

#### Model

			Cylinder	Note 1) Gripping force	Opening/Closing	Note 2)	MHZ	
Operati	ng system	Model	bore (mm)	(Effective value) N	stroke (mm)	Weight (g)	MHF	
Double acting		MHQJ2-10D 10 11 4		4	90			
		MHQJ2-16D	16	34	6	180	MHL	
		MHQJ2-20D	20	42	10	340		
		MHQJ2-25D	25	63	14	640	MHR	
Single acting Norr	Normally open	1 1	MHQJ2-10S	10	7.8	4	90	NAL 11/
			MHQJ2-16S	16	26	6	181	MHK
			MHQJ2-20S	20	33	10	342	MHS
		MHQJ2-25S	25	49	14	643	MIIIO	
		MHQJ2-10C	10	7.8	4	90	MHC	
	Normally	MHQJ2-16C	16	26	6	181		
	closed	MHQJ2-20C	20	33	10	342	MHT	
		MHQJ2-25C	25	49	14	643		
Note 1)	Values at t	he pressure of (	5 MPa Do	uble acting is compatib	le with both exte	arnal and	MHY	

Note 1) Values at the pressure of 0.5 MPa. Double acting is compatible with both external and internal gripping forces, while single acting and normally open external gripping force, and single acting and normally closed internal gripping force.
Note 2) Values excluding weight of auto switch.

MIIK
MHS
MHC
МНТ
MHY
MHW
X
WRHQ
MA
MA D-🗆